



Adjustable LED Work Light

Multi-Use Rechargeable Work Light & Flashlight

Thanks for purchasing another Flipo® product intended to make life a little easier. FLIPO® offers a wide variety of unique products of the highest quality. To ensure the maximum performance of your product, please read and save these instructions.

Figure 1



Figure 2



Figure 3



Figure 4



CHARGING

Your Work Light includes a USB-C charging cable (**Figure 1**). To charge, open the charging port cover located in the handle of your work light and insert the USB-C plug into the USB-C receptacle (**Figure 2**); the other end of the cable should be plugged into a wall charger. While charging, the three LED lights located above the POWER button on the opposite side of the handle will illuminate in red. When fully charged, the three lights will change to green.

OPERATION

Illumination Modes

Your light has 6 illumination modes that are controlled by pressing the red POWER button located on the handle of Work Light. Illumination modes are activated by sequentially pressing the button as follows:

1. Flashlight
2. One COB Panel
3. Two COB Panels
4. Three COB Panels
5. Three COB Panels Flashing (Emergency Signal)
6. Off

If you use any of the above illumination patterns for an extended time, pressing the POWER button again will turn the light off and return it to Mode 1 when reactivated. The red led light above the POWER button will illuminate and show the amount of battery charge remaining while in use.

Folding Light Panels

Your Work Light has three panels that can be independently moved while in use. Simply grasp a panel and pull downward. When not in use, return the panels to their original position; they will snap in place when fully closed.

Your Work Light has a triangularly shaped hanger that can be used to suspend it from a fixed

position of your choice. To access the hanger, all three panels must be fully extended to the out position, (**Figure 3**). Your Work Light also has two magnets that allow for connection to metallic surfaces (**Figure 4**).

PLEASE NOTE THAT CHANGES OR MODIFICATIONS OF THIS PRODUCT IS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received.

CAUTION

1. Fully charge your battery before using your product for the first time.
2. Use only the USB-C cable provided with your product to charge.
3. Do not store your product in a high-temperature environment including heat caused by intense sunlight.
4. Do not place product in fire or other excessively hot locations; exposure to fire or temperature above 212° may cause an explosion.
5. Do not expose your product to rain or snow.
6. Do not drop from high distances.
7. Do not disassemble this product or attempt to modify it in any way.
8. Do not dispose of this product in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental laws.
9. Turn off your light when not in use.
10. Use a damp cloth to clean if necessary.

30 DAYS LIMITED WARRANTY:

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

Flipo Group
613 First Street
La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.



Manufactured by Flipo Group Limited La Salle, IL
Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com
Fax: (815) 223-9266

MADE IN CHINA