




CAMPER CAT SCRATCHER

Instruction Manual

SKU# 6080959

Please read instructions carefully before use. Retain for future reference



Assembled Dimensions

Distributed by:
TRACTOR SUPPLY COMPANY
5401 VIRGINIA WAY,
BRENTWOOD TN 37027
For customer support,
call: 1-888-376-9601
www.TractorSupply.com
MADE IN CAMBODIA

Approximate
assembly time: **20 Minutes**


People
for assembly:




Required assembly space:
Floor area 3.3 ft. x 3.3 ft. (1m x 1m)




PART LIST




Wall A




Wall B




Top



Bottom



Scratcher





Tree

TIP BEFORE YOU START

- * Ensure that all parts are present prior to assembly.
- * Check all packing material carefully before discarding, as some parts may be encased in the packing material.
- * For ease and speed of assembly, it is recommended that prior to each step all required parts are identified.
- * Ensure that you have sufficient space and people (as indicated on page 1) to assemble product safely.

ASSEMBLY INSTRUCTIONS


Step1: Insert the tabs of wall A to connect wall B.



1: Insert interior tab first.


2: When pieces are attached insert second tab to lock in place.

Step 2: Insert the top cardboard and the tree.




ASSEMBLY INSTRUCTIONS

Step 3: Set the scratcher.



Step 4: Insert the bottom cardboard.



Step 5: Finished assembly.

