



Form No. 3480-411 Rev A

Count on it.

Parts Catalog

22in Recycler[®] Max Lawn Mower

Model No. 21485—Serial No. 420600000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Housing Assembly 4

Rear Bag Assembly 6

Deck Decal Assembly 8

Engine and Blade Assembly 10

Front Wheel and Height-of-Cut Assembly 12


Rear Wheel and Height-of-Cut Assembly 14

Handle Assembly 16

Quick Release Lever Assembly No. 138-3249 18

Attachments and Accessories 20


Housing Assembly



Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-8183	1	Housing ASM	14	32104-120	2	Screw-PPH
2	144-6427	1	Baffle-Front	16	139-5476	1	ASM-Rear Door, In Mold
3	46-8091	17	Screw-HWH	16:2	140-2394	1	Artwork-Door, In-Mold
4	139-5440	1	Baffle-Rear, Rwd	18	139-5478	1	Spring-Torsion, LH
7	140-4038	1	Screw-Shldr,HWH	19	139-5479	1	Spring-Torsion, RH
9	140-2368	1	ASM-Chute, In Mold	30	139-5457	1	Bumper-Front
10	139-5443	1	Deflector-Recycle	31	139-5467	3	Screw-Plastic, HWH
11	139-5444	1	Knob-Recycle	32	144-0210	1	ASM-Intake, Rwd
12	139-5445	1	Latch-Recycle	33	140-2384	1	Cover-Intake, Bottom
13	140-4192	1	Spring-Compression	35	161-4751	1	Decal-Vortex


Rear Bag Assembly



Rear Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-5470-03	1	ASM-Frame, Bag
2	139-5471	1	ASM-Bag, Grass


Deck Decal Assembly



Deck Decal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	94-8072	1	Decal-Danger
8	121-5684	1	Decal-Location, Service Dealer
11	161-4750	2	Decal-Recycler Max

Engine and Blade Assembly




Engine and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8		1	Engine-Briggs 104M020254F1 ●■	24	125-2466	1	Bolt-Blade
11	121-5844	3	Screw-Thd Form, HWH	32	145-5603	1	Decal-Briggs 725 Exi SS
13	139-1816	1	Driver-Blade	33	133-8062	1	Decal-Spark Arrestor
20	131-4547-03	1	Blade-22 Inch	34	133-8198	1	Decal-Level, Fuel
22	108-3766-03	1	Support-Blade	35	2210-316	1	Stop-Rope

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-1956-05	2	Plate-HOC,Front Fsvq	8	322-6	2	Screw-HH
2	322-3	4	Screw-HH	9	105-3048	2	Washer-Flat
3	3296-29	6	Nut-Lock, NI	11	139-5449	2	Washer-Wheel Bolt
4	105-1809	2	Arm-Spring	12	144-6469	2	ASM-Wheel, 8" (Bearings)
5	105-3042	2	Knob-Lever, HOC	12:2	52-2450	2	Bearing-Wheel
6	137-9128	2	Arm-Pivot, Front	13	145-3899	2	Wheel Bolt
7	105-1818	2	Bushing-Mount, HOC				


Rear Wheel and Height-of-Cut Assembly



Rear Wheel and Height-of-Cut Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-5651-05	1	Plate-HOC, LH (ISO)	17	110-7191	2	Washer-Thrust
2	145-5650-05	1	Plate-HOC, RH (ISO)	18	131-5399	2	Gear-Pinion, 15T
3	322-3	4	Screw-HH	19	32151-61	2	Ring-Retaining
4	3296-29	4	Nut-Lock, NI	20	140-2362	2	ASM-Cover, Gear (Dk Gray)
5	3229-11	2	Screw-CARR	20:2	614426	1	Washer-Stepped
6	3296-16	2	Nut-Lock, NI	22	163-7210	2	ASM-9.65" Wheel, Geared
7	132-4486	2	Arm-Spring	23	145-3899	2	Wheel Bolt
8	105-3042	2	Knob-Lever, HOC	24	139-5448	1	Cover-Belt, Rwd
9	139-5451	2	Arm-Pivot, Rear	25	46-8091	2	Screw-HWH
10	108-9779	2	Retainer-Bushing, HOC	26	139-6597	1	Shield-Trailing
11	104-8699	2	Bearing-Ball	32	140-2369	4	Pad-Smart Stow
12	108-9782	2	Bushing-Sleeve	33	107-7461	4	Screw-Plastite
13	139-6561	1	Transmission-Rwd	35	139-1692	2	Screw-PTH
14	114-7977-03	1	Bracket-Transmission	36	144-0218	2	Bumper-Isolator
15	140-4041	1	V-Belt	37	144-6540	2	Screw-CARR-Spcl
16	108-7476	3	Screw-Plastite	38	119-4041	2	Nut-HF


Handle Assembly



Handle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	144-6516-05	1	Handle-Curved	33	139-6567	1	Bottom-Handle, RH
6	139-6588	2	Bolt-Shoulder, Handle	34	139-6568	1	Bottom-Handle, LH
7	3296-29	2	Nut-Lock, NI	35	94-4496	10	Screw-PPH
9	117-5976	2	Knob-Handle	36	145-5879-03	1	Bail-Brake
12	138-3249	2	Quick Release ASM	37	139-6594	1	Cable-Brake, Pp B&s
20	140-2367	1	Guide-Curved, LH (Rwd)	38	144-0221	1	Screw-CARR
21	140-2366	1	Guide-Curved, RH (Rwd)	39	139-6581	1	Anchor-Cable, Rwd
24	139-5464	1	Rod-Control, Traction	41	139-6595	1	Cable-Traction, Rwd (Pp)
25	139-6554	1	Lever-Traction, Rwd	46	136-9075	1	Washer-Curved
27	3256-23	1	Washer-Plain	47	3296-73	2	Nut-Lock, NI
30	140-4194	1	Spring-Torsion	48	86-9671	1	Guide-Rope
32	139-6569	1	Handle-Personal Pace, Curved	50	114-7988	1	Guide-Cable
				63	139-6577	2	Pin-Handle, Pp

Quick Release Lever Assembly No. 138-3249



Quick Release Lever Assembly No. 138-3249 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-4157	1	Nut-Push
2	138-3248	1	Lever-Release
3	138-3253	1	Anchor-Spring

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	115-2858	1	Spring-Compression
5	140-4158	1	Rod-Release

Attachments and Accessories

For 21485 — 22in Recycler Max Lawn Mower

Product Name	Model/Part
Fuel Stabilizer .05 oz	130-2393
Briggs Maint Kit.....	130-8148
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Toro Premium Fuel Treatment 12oz Bottle.....	131-6572
Oil-30/10W-30 Synthetic (Quart).....	138-6053
Chute ASM	147-8696
Lawn Striping Kit with 22in Roller	20601
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Summer Oil-Case of 24 (20oz Bottles).....	38916
Smart Stow Walk Power Mower Cover	490-2012
Bag-Walk Behind (Toro).....	490-7318
Lawnmower Cover	490-7462
22 Inch Atomic Blade	59534P

Notes:

Notes:

Notes:



Count on it.