

# Mini Rechargeable Handheld Fan - Instruction Manual

## Sent 01.21.26

alpha<sup>▲</sup>cool™



SCAN THIS QR CODE TO LEARN MORE  
OR VISIT US AT  
[www.ALPHACOOLOPRODUCTS.com](http://www.ALPHACOOLOPRODUCTS.com)


MADE IN CHINA

### Product Cleaning

- Before cleaning, ensure the product is powered off and unplugged.
- The front cover is not removable. Use a clean, dry cloth to wipe the fan surface and air inlet grille.
- Do not clean electrical components (such as motors or switches) with water or other liquids.
- Do not touch the power supply or electrical components with wet hands or cloths.

alpha<sup>▲</sup>cool™

## MINI RECHARGEABLE HANDHELD FAN




SKU: AC-MHF-W | Model: X688

### Product Parameters

SKU: AC-MHF-W | Model: X688  
Product: Mini Rechargeable Handheld Fan  
Rated Input: DC 5V / 1A  
Battery Capacity: 1500MAH  
Charging Time: Approx. 1.5 hours  
Operating Time: 2-6 hours  
Product Size: 1.3 × 1.6 × 3.5 in  
Executive Standards: GB4706.1-2005 | GB4706.27-2008


### Product Description



### How to Use

1. Press and hold the power button for 2 seconds to turn the fan on. The display will light up and the fan will start at Speed 1.
2. Each short press of the power button will increase the speed in the following sequence: Speed 2 → Speed 4 → Speed 6 → Speed 8 → Speed 10.
3. After reaching the highest speed, press the power button again to turn the fan off.
4. The fan supports up to 100 speed levels, depending on continued button presses.

### Set Includes



### Warnings

1. Read all instructions and warnings before use.
2. Make sure to turn the power off when not in use.
3. Do not drop, strike, or subject the product to strong impact, as this may cause internal damage.
4. Do not disassemble, modify, or attempt to repair the product yourself.
5. Do not expose the product to fire or extreme heat to avoid the risk of danger.
6. If the product becomes excessively hot, deformed, or abnormal during charging, stop charging immediately.
7. Do not use while sleeping or unconscious.
8. Children should not use this product without adult supervision.
9. Unattended use of electric products on animals, children or incapacitated persons may be dangerous.
10. Do not use this product while charging.
11. In the rare event of experiencing any sensation of overheating or discomfort while using any AlphaCool™ product, immediately remove product and turn power off.
12. Avoid allowing hair near the air inlet to prevent hair from getting caught in the air cavity.
13. Do not attempt to touch internal turbines or components to avoid potential injury or damage to the product.
14. Do not use excessive force when unfolding the fan as this may damage the product.
15. Do not store below -4°F (-20°C) or above 120°F (49°C).
16. Do not allow fan or internal components to come into contact with water or other liquids. If water or other liquids enter the fan's interior while in use immediately remove the fan and turn it off. Continued use of a potentially damaged product may result in fire or an electrical shock.
17. It is important to maintain at least 25% of your battery power when not in use. Failure to do this will result in performance problems and reduced battery life.
18. Recycle in accordance with local regulations.