

PN 2025028123



Small Livestock Feeder



Quick Start Guide



Scan for Product
Support

REV: 05.29.26

CCD-0010793

⚠ CAUTION

**MOVING PARTS CAN PINCH, CRUSH OR CUT. KEEP CLEAR AND USE CAUTION.
TWO-PERSON LIFT RECOMMENDED FOR ROOF PANELS TO PREVENT STRAIN OR**

LOSS OF CONTROL

KEEP HANDS CLEAR OF PANEL EDGES AND MOUNTING POINTS.

WEAR GLOVES TO PROTECT FROM SHARP EDGES.

ENSURE FEEDER IS ON A LEVEL, STABLE SURFACE BEFORE INSTALLATION.

DO NOT CLIMB OR STAND ON FEEDER DURING INSTALLATION.

Resources Required

⚠ 5/16" Socket

⚠ 5/16" Wrench

Packaging



The feeder ships shrink-wrapped and largely pre-assembled. End-user assembly is limited to the roof system including:

⚠ Roof cap (x1) - PN 2025011138

⚠ Roof panels (x2) - PN 2026071899

⚠ Bolt, washer, nut (x4) - PNs 377775, 217252, 376094

Note: Fasteners are shipped installed in the feeder columns. Uninstall and retain for steps 3 and 4.



Installation

1. Install the roof cap (**Fig.1**) into the feeder columns, pushing down until the fastener holes align.

2. With two people, position the first roof panel under the roof cap and align the panel frame holes with the column holes.

3. Install two bolts (**Fig.2A**) with washers on each end of the roof panel through the column and roof cap.

4. Install the second roof panel onto the protruding bolts (**Fig.2B**) and secure with nuts (**Fig.3**).



Fig.1




Fig.2




Fig.3

Manual information may be distributed as a complete document only, unless Lippert provides explicit consent to distribute individual parts.

All manual information is subject to change without notice. Revised editions will be available for free download at lippert.com. Manual information is considered factual until made obsolete by a revised version.

Please recycle all obsolete materials and contact Lippert with concerns or questions.

