



TOMAHAWK

eTMD14
BATTERY POWERED FOGGER

Parts Manual




FRAME & POWER UNIT



FRAME & POWER UNIT			
#	Part Number	Part Name	Qty.
1	3WBD-8-4	Frame	1
2	GB/T 96.1	Washer 6	7
3	GB/T 6177.1	M6 Nut	7
4	3W-950.5	Rubber Pillar	3
5	3F-30.12	Rubber Pillar	2
6	3W-15A.2-1	Volute Case	1
7	GB/T845 ST4.8×19	St4.8×19 'Screw	12
8	GB/T889.1	M8 Nut	1
9	GB/T93	Washer 8	1
10	GB/T96.1	Washer 8	1
11	3WBD-8.1.3	Impeller	1
12	3WBD-8.1.1-1	Door Axle	1
13	ZB4-01	Guide Pipe	1
14	3W-15A.1	Chemical Tank	1
15	GB/T9074.13	Screw Assem M6X30	2
16	ZB200-D80.5-3	Retainer Plate	2
17	3WBD-8.2.2	Cell Connector	1
18	3WBD-8.2.5	Controller	1
19	3WBD-8.5	Motor Assembly	1
20	3WBD-8-2	Battery Door	1
21	ZB-200-D.2	Battery	1
22	3WBD-8-1	Front Cover	1
23	3WBD-8-3	Right Cover	1
24	3GC36D.2-4	Screw	4
25	XSS46-2.2-5	Screw	8
26	ZB200-D80.5-4	Battery Ejection Spring	2
27	3WBD-8.3	Hasp Assembly	1

THROTTLE CONTROL & BLOWER ARM



THROTTLE CONTROL & BLOWER ARM			
#	Part Number	Part Name	Qty.
28	3F-30.18-4	Rubber Sleeve	1
29	JB8870 (φ70-φ90)	Hoop	2
30	3WF-8.11-1	Tube	1
31	EB-650.7.1	Blowpipe	1
32	3WF-2.6B.4	Support	1
33	GB/T70.1+GB/T93+GB/T848	Screw Assem M5×16-10.9	3
34	3W-950.4	Rubber Pillar	2
35	3WF-3.19-1	Clip	4
36	LS-10×1.5×800	Tube	2
37	3WF-3.19.1	Cock Assem	1
38	EB-650.5.3	Lock Screw	1
39	3WBD-8.2	Handle	1
39_1	GB9074.4 5×20	Screw Assem M5×20	1
39_2	3WBD-8.2-2	Self-Locking Handle	1
39_3	3WBD-8.2-5	Left 'Handle	1
39_4	GB889 M5	Nut M5	1
39_5	3WBD-8.2.4	Speed Switch	1
39_6	3WBD-8.2.1	Microswitch	1
39_7	3WBD-8.2-4	Right 'Handle	1
39_8	BL750.3-7	Locking Spring	1
39_9	3WBD-8.2-3	Button	1
39_10	3WBD-8.2.3	Wire Harness	1
39_11	PWA M3×10 帽12mm	Screw M3×10	2
39_12	3WBD-8.2-1	Knob Switch	1
39_13	3GC36D.2-4	Screw	5
40	3W-16.8-2A	Tube	1
41	3WF-2.6.4.3	Nozzle Assembly	1
42	3W-950.2-2	Damper Shaft	1
43	GB/T845	St2.2*13 'Screw	2
44	3W-950.2-1	Tube	1
45	3WF-2.6.4.3	Damper Plate	1
46	150BT-M2-4	Hanging Scroll	4
47	3WBD-8.4	Bands Assm	1
48	GB/T823+GB/T96.1	Screw Assem M6×12	4