



Thank you for choosing Haunted Hill Farm!  
If you have any questions, concerns or suggestions,  
please contact us directly.

**Boo@HauntedHillFarm.com** (Anytime)

**1-888-840-4559**

9AM-9PM EST Monday-Friday

9AM-5PM EST Saturday-Sunday

In the unlikely event that you experience a problem, please provide pictures and a description of the problem, a receipt (if available), name and address of the purchaser and the name of retailer where you purchased the product.

If you picked up your product up at a retail store, please also advise the name, city and state of the store where you received your product.

**Please do not return this item to the retailer.**

See the full Haunted Hill Farm collection and get online support for assembly, troubleshooting, care and maintenance at:

**[www.HauntedHillFarm.com](http://www.HauntedHillFarm.com)**

**Follow us on social!**

**Facebook & Instagram: @officialhauntedhillfarm**

**YouTube & TikTok: @hauntedhillfarm**

Please follow the step by step guide and enjoy your-

HHAPCLYPSTWNS-1FLSA



The model number of your item is printed on the side of your carton.  
Always use this number to identify your item.

Thank you for your purchase of this quality Halloween decor. With proper use and care, your Halloween decor will provide you with years of enjoyment. Please follow the instructions on how to assemble and disassemble your item. If you should have any problems with your item, or you have any questions, **DO NOT** return it to the place of purchase. Please call our toll-free number: **1-888-840-4559** and a customer service representative will assist you. Enjoy your Holiday!

## PARTS LIST

- A. Base x 1
  - B. Boy's Shoes x 2
  - C. Girl's Shoes x 2
  - D. Leg Poles x 4
  - E. Boy's Pants x 1
  - F. Girl's Pants x 1
  - G. Leg Foam Tubes x 4
  - H. Boy's Body Frame x 1
  - I. Girl's Body Frame x 1
  - J. Boy's Costume x 1
  - K. Girl's Dress x 1
  - L. Boy's Left Arm x 1
  - M. Girl's Right Arm x 1
  - N. Arms Assembly x 1
  - O. Boy's Head x 1
  - P. Girl's Head x 1
  - Q. Toy Bear x 1
  - R. Adapter x 1
- Input: 100 - 240VAC 50/60Hz  
Output: 5.9V 3.0A



**BEFORE ASSEMBLING, REMOVE ALL THE ABOVE PARTS FROM BOX.  
IF ANY PART IS MISSING, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT.  
CONTACT CUSTOMER SERVICE AT [BOO@HAUNTEDHILLFARM.COM](mailto:BOO@HAUNTEDHILLFARM.COM),  
OR BY PHONE 9AM-9PM EST MONDAY-FRIDAY,  
9AM-5PM EST SATURDAY-SUNDAY AT 1-888-840-4559.**

## CARE AND STORAGE INSTRUCTIONS





For best performance operate your item indoors.  
When the product is not in use, store in its original packing after it is completely dry.  
Keep away from heat.  
Please read all instructions carefully before assembling.  
Save this instruction sheet for future reference.

## WARNING


This item is not a toy and should be used for decoration only.  
This item contains small parts that can be a choking hazard.  
Keep all plastic and wire parts away from children. Recommended for ages 15 and up.

1. Please use the adapter supplied by manufacturer.
2. Please assemble item according to instructions. Connect all wires according to matching letters.
3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard.  
Keep all away from the adapter, as it heats up during operation.
4. This item contains Polyvinyl Chloride (PVC).
5. Colors, style and contents may vary slightly from those shown on the package.

# ASSEMBLY INSTRUCTIONS




# ASSEMBLY INSTRUCTIONS




## STEP 5

Set the forked hook of the (L) Boy's Left Arm to the housing at the left side of the (H) Boy's Body Frame then set the forked hook of the (M) Girl's Right Arm to the housing on the right side of the (I) Girl's Body Frame as shown in Figure 1. Secure the left sleeve of the (J) Boy's Costume to the hand of the (L) Boy's Left Arm using the hook and loop closure available as shown in figure 2. Secure the right sleeve of the (K) Girl's Dress to the hand of the (M) Girl's Right Arm using the available hook and loop closure as shown in Figure 3.




## STEP 6

Slide the (N) Arms Assembly up the right sleeve of the (J) Boy's Costume and slide the other part up the left sleeve of the (K) Girl's Costume as shown in Figure 1. And set the forked hook available on both sides of the (N) Arms Assembly into the housing available on the right side of the (H) Boy's Body Frame and the other forked hook into the housing on the left side of the (I) Girl's Body Frame as shown in Figure 2.



## STEP 7

Set the forked hook of the (O) Boy's Head to the forked hook housing on top of the (H) Boy's Body Frame then set the forked hook of the (P) Girl's Head into the forked hook housing available on top of the (I) Girl's Body Frame as shown in Figure 1. Set the forked hook of the (Q) Toy Bear into the housing available on the (N) Arms Assembly then connect the cable from the (Q) Toy Bear to the wire from the (N) Arms Assembly as shown in Figure 2.



## STEP 8

Connect all cables according to their shapes as shown in Figure 1. Secure the Sensor into the hole at the front side of the (K) Girl's Dress using the available hook and loop closure as shown in Figure 2.

# ASSEMBLY INSTRUCTIONS



## STEP 9

Close the backs of both (J, K) Costumes using the available hook & loop closures as shown in Figure 1.

**SENSOR HERE**  
Be sure nothing is blocking the sensor.



## STEP 10


Your Apocalypse Twin is now fully assembled. Plug in and turn on and let the fun begin!

# OPERATING INSTRUCTIONS

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the (I) Girl's Body Frame, as desired.

2. Settings:

|                   |                                                                                                                                                                                                                                                                                                                                                    |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SENSOR</b>     | This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 activity cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below. |
| <b>OFF/TRY ME</b> | This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad (Included). The item will operate for one activity cycle with each Try Me activation.                                                                                                                                                |
| <b>ON</b>         | This switch mode will continually operate the lights, sound, and animation of the item.                                                                                                                                                                                                                                                            |
|                   | Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off.                                                                                                                                                                                                                                        |



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

FCC responsible party: Seasonal Visions International

Address: San Diego, CA 92101

Email: CUSTOMERSERVICE@SVICHINA.COM



## Warnings

- This product is for decoration only and is not a toy. Small parts and choking hazard. Use caution with children under the age of 15.
- Do not position the decoration near candles, sources of heat, or in direct sunlight.
- The decoration cannot be connected to the power supply directly.
- Decoration should be on a level, stable surface to prevent it from falling over.
- This product is fragile and should be assembled with care.
- Surface washable only.
- Please follow the steps and requirements specified in the instruction to ensure safety and reliability during the installation.

**Warning! This item is not a toy. For decoration only. Small parts, choking hazard.  
This product is intended for use by persons 15 years of age and older.  
Not intended for use by children ages 14 years and younger.**

**WARNING**  
**DO NOT TURN ITEM ON UNTIL YOU HAVE COMPLETELY FINISHED ASSEMBLY.**  
**STAY CLEAR OF ITEM WHILE OPERATING.**  
**DO NOT PLACE ITEM ON UNEVEN GROUND.**  
**DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION.**

**Storage tips:** We suggest saving the carton for storing your figurine. Store in a cool, dry area where the temperature does not exceed 100°F.

# 1-YEAR LIMITED WARRANTY

## "Limited" Warranty Program

For a period of one (1) year after purchase, Haunted Hill Farm ("Manufacturer") will either repair or replace defective components in accordance with this Limited Warranty.

**Sales and use taxes, plus shipping and handling charges are the responsibility of the consumer.**

This warranty is between Manufacturer and the original purchaser and is valid only when accompanied by the original purchaser's sales receipt showing original date of purchase and location of purchase. Replacements under this warranty revert back to the date of original purchase for future warranty.

Manufacturer or its authorized dealer can accept or reject warranty claims based on its findings. This warranty applies in normal residential use only, where an issue with the product is due to a defect in material or workmanship. Manufacturer can make substitutions as required of materials, components, and sub-components of comparable value and utility. This warranty is limited to product repair or replacement (to be determined solely by Manufacturer). Warranty return is limited to only the single affected component.

This warranty covers only manufacturing defects and does not cover normal wear and tear, abuse or misuse, including: water damage, chemical damage, exposure to extreme heat or cold, abrasion or excessive weight. This product is intended to be used with standard ornaments only. This warranty is invalid if the product is not used for intended purpose. Manufacturer disclaims liability for any aspect of installation and any inconvenience caused by a defective part or component.

**Certain items are not covered by this warranty. These include, but are not limited to the following:**

1. Components subjected to abuse, including abuse intended to simulate failure.
2. Damages caused by retailer, shipper or installation crew (such as scratches, dents, tears, etc.).
3. Any part which merely exhibits normal wear yet functions essentially as new, including stretching of materials and stitching.
4. Tears, punctures, scratches or any damage caused by improper installation or use.
5. Items sold "as is" or floor models.

To make a claim, send a copy of the original sales receipt along with a brief description of the problem to the email address below. Please include your email address and daytime telephone or cell phone #. All items maybe charged actual freight and handling costs. Repairs or replacement will be made at the Manufacturer's option.

**THIS IS THE ENTIRE EXCLUSIVE EXPRESS LIMITED LIABILITY. THE MANUFACTURER NEITHER MAKES NOR IS RESPONSIBLE FOR ANY OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING THOSE OF RETAILING DEALERS. THIS EXCLUSIVE REMEDY IS LIMITED TO RECEIPT OF A CREDIT IN CONNECTION WITH THE REPAIR OR REPLACEMENT OF ANY PRODUCT OR COMPONENT DEEMED TO BE DEFECTIVE UNDER THE TERMS AND CONDITIONS AS STATED IN THIS WARRANTY. NEITHER HAUNTED HILL FARM, THE PRODUCT MANUFACTURER NOR ITS AGENTS SHALL BE LIABLE IN ANY CASE FOR INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY OR NEGLIGENCE EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCEPT AS OTHERWISE MAY BE REQUIRED BY LAW, THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OTHER THAN THE WARRANTY DESCRIBED HEREIN, AND ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY DISCLAIMED.**

**Boo@HauntedHillFarm.com**