



INSTRUCTION MANUAL

ALUMINUM STOCKPOT

MODEL NO. AP-12



PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE.



Price Zone dba

International

COMMERCE, CA 90040
SUPPORT@GASONE.COM
TOLL FREE: 1.800.698.5070
CUSTOMER SERVICE HOURS:
M-F: 9 AM-5 PM PST

FOR CALIFORNIA CONSUMERS ONLY:



WARNING

CANCER AND REPRODUCTIVE HARM.
GO TO WWW.P65WARNINGS.CA.GOV



TABLE OF CONTENTS

WARRANTY INFORMATION	2
SAFETY INFORMATION AND WARNINGS	3
ASSEMBLY	3
DETERMINING PROPER LEVELS	4

WARRANTY INFORMATION

LIMITED WARRANTY

GASONE warrants that for the period of one year this product, will be free from defects in material and workmanship. GASONE, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement will be made with a similar product of equal or greater value. This is your exclusive warranty. This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. GASONE dealers, service centers, or retail stores selling GASONE products do not have the right to alter, modify or in any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than GASONE or an authorized service center. Further, the warranty does not cover acts of God, such as fire, flood, hurricanes and tornadoes.

GASONE shall not be liable for any incident or consequential damages caused by the breach of any express or implied warranty or conditions. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty or conditions. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province. How to obtain warranty service: do not return this product to the store. Call 1(800) 698-5070 or write us at GASONE, 6211 Randolph St. Commerce, CA 90040. Be prepared to give your name, address, model number, description of the problem, phone number, and proof of retail purchase (sales slip).

DISCLAIMERS

Apart from the warranty and disclaimers as described in this warranty statement, there are explicitly no further warranty or voluntary declarations of liability given here which go beyond the statutory liability applying to us. The present warranty statement also does not limit or exclude situations or claims. This warranty statement does not limit or exclude any situations or claims where liability is mandatory under applicable law.

You assume the risk and liability for loss, damage, or injury to you and your property and/or to others and their property arising out of the misuse or abuse of the product or failure to follow instruction in the accompanying owner's manual.


This warranty applies to private single family home or apartment use only and does not apply to appliances used in commercial, communal, or multi-unit settings such as restaurants, hotels, resorts, or rental properties.

We may from time to time change the design of its products. Nothing contained in this warranty shall be construed as obligating to incorporate such design changes into previously manufactured products. Nor shall such changes be construed as an admission that previous designs were defective.

ASSEMBLY

Required Tools: Adjustable Wrench and Screwdriver

Insert the M5 Bolts through the Basket Handle and Basket, tighten 3 Nuts .



DETERMINING PROPER LEVELS

Never overfill the cooking vessel with oil, grease, or water.

Follow the below instructions to determine the amount of cooking liquid to be used.

1. Place the food into the basket.
2. Place the food product and basket into the empty vessel.
3. Fill the vessel with water until the food is completely submerged. There must be a minimum of 3 in (7.5 cm) between the water level and top of the vessel.
4. Remove the food product from the vessel and either mark the water level on the side of the vessel, or measure the amount of water in the vessel.
5. Remove the food product and completely dry the vessel and the food product.
6. This is the amount of cooking liquid the vessel is to be filled with to cook the food.