

BATTERY SAFETY

- Insert batteries according to the correct polarity (+ / -).
- Do not mix old and new batteries.
- Do not mix different types of batteries (alkaline, standard carbon-zinc, or rechargeable).
- Use only the recommended battery type specified for the product.
- Remove exhausted batteries promptly.
- Remove batteries if the product will not be used for an extended period, where applicable.
- Rechargeable batteries should only be charged under adult supervision.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit battery terminals.
- Do not dispose of batteries in fire.
- Recycle or dispose of batteries properly according to local regulations.

FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

Instruction manual shall include,

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

FCC Radiation Exposure Statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in the portable exposure condition without restriction.

30 DAYS LIMITED WARRANTY:

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty. During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

Flipo Group
613 First Street
La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

BATTLE TANK

RC Battle Tank Set



FOR AGES 8+ | Model: TOY-BATTLETANKS



Manufactured by Flipo Group Limited La Salle, IL
Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com
MADE IN CHINA

Instruction Manual

Please read this instruction manual carefully before using.

Contents:

- 2 x Flipo Battle Tanks
- 2 x 2.4GHz Remote Controls
- 2 x Rechargeable 4.8V 700mAh Battery Packs
- 2 x USB-A to Battery Wire Connector Charging Cables



Battery Installation & Charging

Before first use

Fully charge your tank's batteries using ONLY the included USB-A to battery wire connector charging cables.

IMPORTANT: The initial charging time will be approximately 8-10 hours to ensure the battery packs receive a complete charge. Subsequent recharging time will be approximately 3-4 hours.

Charging the batteries

1. Remove the rechargeable battery packs from the accessories packaging.
2. Plug the battery wire connector into the appropriate connector on USB-A charging cables.
3. Plug the other end of the charging cables into a USB port or an adapter to use an AC plug.
4. The red indicator light on the charging cables will light when charging.
5. When charging is complete the red light will turn off.
6. Disconnect battery wire connectors from charging cable wire connectors.
7. Reconnect the battery wire connectors to the wire connectors in the battery compartments.
8. Place each battery into the compartment.
9. Replace the compartment covers and tighten the screws until snug.

Installing Remote Control Batteries

1. Locate the battery compartment on the back of each remote control.
2. Loosen the screw and remove the battery compartment cover.
3. Insert 1.9V battery according to the polarity graphic on the inside of the compartment.
4. Replace the cover and tighten the screw until snug.
5. Repeat these steps for the other remote control.

Operation

Note: Pair each tank with the matching remote control by using the corresponding camouflage color buttons/thumb joysticks to ensure proper frequency connection.

Linking The Tank & Remote Control

1. Locate the power switch on the underside of the tank and move it to the ON position.
2. The tank will beep once to signal that it is turned ON.
3. Press the start button located to the right of the fire button on the remote control.
4. The tank's engine sound will start and the four Life Value red LEDs on the top rear of the tank will light.
5. Repeat these steps for the second tank.

Auto-Demo Mode

1. Press the auto-demonstration button located to the left of the fire button on the remote control.
2. The tank will automatically demonstrate many of its driving and combat functions.

Battle

NOTE: The tanks can battle each other from up to 10 meters away.

1. The right thumb joystick controls the right track of the tank. Push the joystick forward or backward to move the right track in the selected direction.
2. The left thumb joystick controls the left track of the tank. Push the joystick forward or backward to move the left track in the selected direction.
3. Using one joystick at a time will cause the tank to turn or spin. Push both thumb joysticks forward at the same time to move the tank forward.
4. Push both thumb joysticks backward at the same time to move the tank in reverse.
5. Pushing both thumb joysticks in the opposite direction will spin the tank in the direction of the reverse thumb joystick.
6. The turn left and turn right buttons on the top of the remote control will turn the gun turret in the corresponding direction.
7. For canon fire, press the fire button.
8. For rapid fire, simultaneously push the desired turn right/turn left button while pressing the fire button.

Life Value Lights

- To score a kill on your opponent:
- One direct canon hit equals one Life Value light.
- Five rapid-fire machine gun hits equals one Life Value light.
- When a Life Value light is used the light will turn OFF.
- Note: If you fire shots and do not score a hit, you may need to reposition your tank.
- When your four Life Value lights have been used, they will all flash, signaling defeat.
- After an approximately fifteen second pause, the Life Value lights will turn OFF. Press the start button to turn them back ON and return to battle.

WARNINGS:

- Wipe the product clean with a soft, dry cloth when needed.
- Store the product in a cool, dry place when not in use.
- Turn the product off when not in use to conserve battery life, if applicable.
- Keep the product away from heat sources, open flame, and direct prolonged sunlight.
- Do not use near water or in wet conditions unless specifically designed for water use.
- Do not modify, disassemble, or otherwise alter the product.
- Discontinue use if the product becomes damaged, overheats, or malfunctions.
- Keep fingers, hair, loose clothing, and small objects away from moving parts, where applicable.
- Adult supervision is recommended during setup, charging, and battery installation, where applicable.
- Use only the included or recommended accessories and charging components, where applicable.
- Follow all operating instructions before use.
- Keep packaging materials away from children and dispose of properly.
- Not suitable for children under the recommended age listed on packaging.