

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

OUTDOOR SPOTLIGHT

MODEL: JS-CDD002

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

OUTDOOR SPOTLIGHT

MODEL: JS-CDD002



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

IMPORTANT SAFEGUARDS

Please read and understand this entire manual before attempting to assemble, operate or install the product.

WARNING:

- Be careful to open the carton, contact us if there is any damage.
- Non-professional technicians, please do not repair or modify this product without authorization.
- To ensure the lifetime of the product, please do not use it in a place with strong acid mist.

● The luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 0.5m is not expected

To reduce the risk of fire, electric shock, or injury:

- Turn off the circuit breaker before installing this fixture.
- This product should be installed by someone familiar with the construction and operation of the product and the hazards involved. Safety eyeglasses and gloves are recommended.
- Abide by related regional and local laws or regulations.
- Proper grounding is required to ensure safety.
- This fixture was designed for daisy chains only. Using it for other purposes will void the warranty.
- Check for shipping damage before installing. If the product is damaged, do not use it.
- Keep the fixture away from corrosive substances.
- Suitable for damp locations at temperatures ranging from 4°F to 113°F. Not for use where directly exposed to water.
- Clean the fixture regularly to ensure proper operation. Do not clean with harsh solvents.
- Use safety precautions and abide by regional and local laws or regulations.

SAVE THESE INSTRUCTIONS

FCC INFORMATION

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This product may cause harmful interference.
- 2) This product must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this product are not expressly approved by the party. Responsible for compliance could void the user's authority to operate the product.

Note: This product has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the distance between the product and receiver.
- Connect the product to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.


PACKING LIST

Product Parameter	
Product model	JS-CD002
Size	
Material	Aluminum die-casting
Input Voltage	AC/DC12-24V
Power	6W
CCT	3000K
Ambient temperature	4°F to 113°F
Power cables	White+ /Black-

PURCHASING INSTRUCTIONS

- 1, outdoor installation must use waterproof power supply
- 2, be sure to use with 12 or 24V power supply
- 3, white positive, black negative, shall not be reversed
- 4, do not directly connect 220V electricity, otherwise it will directly burn the drive and light source
- 5, lighting equipment must be disassembled, connected and tested by qualified technicians
- 6, the light source of this lamp is not replaceable, when the light source to its end, should replace the entire lamp
- 7, such as misuse or not in accordance with the use of specifications, the result is not within the scope of warranty returns
(AC or DC power supply must be purchased separately)

Installation diagram:




Wiring diagram:





Attaching Your Fixtures

Turn the transformer on. Attach your fixtures to the cable to using cable connectors as shown. Place one connector on each side of the cable, then press together to lock. Prongs will pierce the cable to make contact and your fixtures should light up. Turn the transformer on. Attach your fixtures to the cable using the cable connectors as shown. Press the connector tight onto the cable until the prongs pierce the cable insulation. The fixture should light on.



VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support

Made In China