



Upgrade · The Home Creator Way

Ramp

Model:OLT-LPD001 /OLT-LPD002

VEVOR Support Center



OLT-LPD001




OLT-LPD002

Model: OLT-LPD001 /OLT-LPD002



OLT-LPD001



OLT-LPD002

Read the instructions carefully before using the device.

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

Catalogue

1. Technical parameters
2. Safety precautions
3. Save these instructions
4. Common fault analysis

1. Technical parameters

Model	OLT-LPD001	OLT-LPD002
Single load capacity (lbs)	3000	3000
Maximum Load Bearing (lbs)	6000	6000
Product size	2130×355×60mm	1530×304×60mm
Material	Aluminum	Aluminum
Color	Silver	Silver

2. Safety precautions

	Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual, including all text under subheadings, before setting up or using this product.
---	--



WARNING

TO PREVENT SERIOUS INJURY:

Before loading or unloading, turn the vehicle's engine off, set its transmission in gear or park, engage its emergency brake, and block its wheels. Make sure the Ramps are clean and dry before loading or unloading.

Instructions are as follows:

1. The ramp surface must be dry, clean, and free from oil or grease.
2. Park the vehicle or trailer on flat, firm ground; be sure the vehicle is **PARKED** with the emergency/parking brake **ON** and the engine turned **OFF**.
3. Place ramps on the tailgate or trailer to accommodate the wheelbase of the loading vehicle.
4. Ensure the plate or fingers of the ramp are securely in place.
5. Warning-To reduce the risk of injury, user must read instructions manual carefully.

6.The product complies with relevant standards and regulations. Installation of this device must comply with all applicable regulations, and it should only be operated in well-ventilated areas. Please read the user manual before installing and using this equipment.

7.This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

8.Children shall not play with the appliance

9.Please properly keep product. Check whether the product is abnormal before use. If it is abnormal, please stop using it.

10.Please use the product according to the intended use, warn of potential injury from misuse.

Motorcycle use:

1. NEVER ride a Motorcycle or any other motorized equipment up or down a single-runner loading ramp.

2. Slowly push the machine up the ramps, MAKING SURE TIRES ARE CENTERED ON THE RAMP AT ALL TIMES. (Two or more adult people are recommended for loading.)

3. Acceleration must be slow, controlled, and constant. The operator must always maintain control of machinery during loading and unloading.

4. Use the brake as necessary to control your speed while unloading. Sudden or erratic braking or accelerating will cause ramps to pull away from the tailgate or trailer or even break the ramp.

ATV use:

1.Always have a second adult to spot for the rider when loading.

2. Slowly drive the machine up the ramps, MAKING SURE TIRES ARE CENTERED ON THE RAMP AT ALL TIMES.

3. Acceleration must be slow, controlled, and constant. The operator must always

maintain control of machinery during loading and unloading.

4. Use the brake as necessary to control your speed while unloading. Sudden or erratic braking or accelerating will cause ramps to pull away from the tailgate or trailer or even break the ramp.

WARNING – NEVER EXCEED THE MAXIMUM LOAD CAPACITY OF THE RAMPS. USE AT YOUR OWN RISK.

Failure to follow these procedures may result in damage to machinery, injury or death. The seller is not responsible for misuse or damages incurred during the use of the ramps.

3. Save these instructions

1. The ramps will sit on the tailgate and both of the ramps must be dry and clean. Check for and tighten any loose hardware.

2. Sit the tongue (angled lip) of the Ramps on the tailgate. The Tongue Edge must face down (see Assembly), and fully contact the truck's tailgate. Extend the Safety Chain (not included) on each Ramp up into the inside of the truck bed; attach each Safety Chain to a secure attachment point on the truck chassis.

3. Pull the loading ramps back until the chains are tight. The entire tongue portion of the ramps must fit onto the tailgate; if not, adjust the Safety Chains accordingly or shorter chains must be used.

4. Common fault analysis

fault phenomenon	failure cause	solution
The ladder deformation	The actual load weight exceeds the maximum product load	The actual load weight does not exceed the maximum product load

