Neon Sign
User Manual

NEON SIGN

Indoor/outdoor sign made from LED bulbs, silicone strips and ABS materials. Create the look of neon without the risk of neon in an outdoor sign. Low voltage with indoor/outdoor adapter plug.

FEATURES


LED BULB embedded in acrylic
OVERALL CORD LENGTH: 67 inches
ADAPTER PLUG suitable for indoor or outdoor use

HOW TO USE

1. Gently unpack your neon sign and remove the protective film and bubble wrap before use.
2. Find your location for your neon sign, providing a flat surface.
3. Attach the cord to the adapter, screwing the adapter closed for a weather resistant seal.
4. Plug the adapter into a working outlet or properly rated extension cord.
5. Neon sign will automatically turn on when plugged in. To turn off, unplug.
6. Box is suitable for storage when not in use.

PACKAGE INCLUDES

1 Acrylic Neon Lights
1 Adapter
1 Product manual



Align and insert the two neon pieces.