
Neon Look Outdoor Sign with Stakes User Manual

This product is made with LED lights, ABS plastic, and silicone strips to create a neon-style appearance without using glass or neon gas. It operates at a low voltage, making it safer than traditional neon signage.

FEATURES

LED Bulbs | 78in cord length | UL-cord. Outdoor rated. | Metal Frame and Stakes

HOW TO USE



1. Unpack your neon sign from the storage box. Remove the protective film and bubble wrap.
2. Attach the frame. See diagram, Steps 1 and 2
3. Connect the power cord. See diagram, Step 3
4. Plug the cord into a wall socket, extension cord or power strip.
5. Store in original box when not in use

OTHER NOTES FOR USE

1. Clean the sign with a soft cloth. Do not spray with liquids or submerge in liquids.
2. Do not bend the cord to breaking point
3. Discontinue use if cord or plug is damaged or bent.
4. Discontinue use if ABS plastic sign is damaged, broken or chipped.
5. Dispose of damaged product according to your local regulations.