
Owner’s Manual

Fire Horse™

Hearthcrest 26” Fire Pit

Model Number: FP26-COB



Safety Information

PRECAUTIONS

Use caution and common sense when using your outdoor fireplace. Failure to adhere to the safety warnings and guidelines in this manual could result in bodily injury or property damage. Save this manual for future reference.



DANGER: To prevent personal injury, burns, property damage, or even death, carefully monitor all activity and alert all persons in the vicinity of burning outdoor fireplaces of the dangers and safety precautions associated with open flame fireplaces. Do not use outdoor fireplaces where alcoholic beverages are being consumed.



DANGER: Keep children, pets, loose clothing, and hair safely away from the outdoor fireplace. Failure to adhere to this could lead to severe personal injury or possible death. Do not allow children to use or play near this outdoor fireplace.



DANGER: Do not use indoors due to the hazard of carbon monoxide fumes and fire. Lack of ventilation may cause death.



WARNING: For outdoor use only.



WARNING: Outdoor fireplaces are only to be used in a well ventilated area a minimum of 20 ft. from building walls, overhangs, trees, and so forth to prevent fires or melting of materials from buildings.



WARNING: Do not place the outdoor fireplace where flames could ignite combustible materials such as roof overhangs, wooden structures, fuel, clothing, fabric, or dry vegetation.



WARNING: To avoid fire hazards, never leave a burning outdoor fireplace unattended. If you must leave the area of the fire pit, ensure that all fire embers are extinguished.



WARNING: Never use gasoline, kerosene, alcohol, or other flammable fuel in or around the outdoor fireplace. Do not use the outdoor fireplace near gasoline or other flammable liquids, gases, or where flammable vapors may be present.



WARNING: Place the outdoor fireplace out of the way of pedestrian traffic, trees, and tree branches.



WARNING: Use with extreme care and at your own risk.



WARNING: The metal surface can get very hot and caution must be used when handling the fireplace after use. Never move the outdoor fireplace when in use or immediately after use when it may be hot.



WARNING: Do not touch the flame or outdoor fireplace when in use.



WARNING: Do not use during windy conditions.



WARNING: Please check with your local fire municipality or authority on any restrictions of use.



WARNING: Do not overload the bowl beyond 6 to 8 pounds.



WARNING: Place the outdoor fireplace on firm, level ground or surfaces free of debris. Do not use on wooden or composite decks.



WARNING: It is advised that a fire extinguisher be readily available. Refer to your local authority to determine the proper size of the fire extinguisher.



WARNING: Do not use the outdoor fireplace for other than its intended purpose.



WARNING: Do not attempt to service or modify the fireplace other than normal maintenance procedures as explained in the Care and Cleaning section of this manual.



WARNING: Metal surfaces will become extremely hot during use. Always use caution when handling a spark screen and a screen lifting tool, if equipped. Failure to wear flame retardant, protective gloves while handling steel parts may lead to serious burns and injury.








WARNING: Combustion by products produced when using this product include carbon monoxide, a chemical known in the state of California to cause birth defects or other reproductive harm.



WARNING: This product contains chemicals known to the state of california to cause cancer, birth defects and/or reproductive harm..

Parts List – 26” Hearthcrest Fire Pit

Letter	Illustration	Description	Qty.	Letter	Illustration	Description	Qty.
A		Tabletop	1	E		Ring Connector	1
B		Bowl	1	F		Bolt	12
C		Legs	4	G		Allen Wrench	1
D		Center Cross Brace	1				

Assembly Instructions
26” Hearthcrest Fire Pit

Important:

- Read all the instructions before assembly. Failure to do so may result in faulty assembly and potential injury.
- Before assembling the product, remove all protective materials, hardware kit(s), and identify all parts packed in the carton that are present. (Note: If any part is missing or damaged, do not attempt to assemble). Contact Fire Horse Customer Support. See page 7.
- Assemble product on a soft and non-abrasive surface, such as carpet to avoid damaging the item.
- Do not tighten bolts until noted after each step.
- Two people are required to assemble heavy items.

Step 1: Connect the Center Cross Brace (D) to the Table Legs (C) using Bolt (F). See Figure 1-1. **Do not tighten bolts until after step 2.**




Figure 1-1

Step 2: Attach Ring Connector (E) to Table Legs (C) using Bolts (F). See Figure 2-1. **Tighten all bolts.**




Figure 2-1

Step 3: Insert Bowl (B) into Ring Connector (E). See Figure 3-1.




Figure 3-1

Step 4: Place Tabletop (A) on Ring Connector (E) to function as a table when fire pit is not in use. See Figure 4-1.
Note: Fire must be completely cooled before using tabletop cover.




Figure 4-1

Maintenance & Care

Maintenance is required for all fire pits. Inspect all hardware thoroughly before use and during the season to make sure bolts are securely fastened. The fire pit must be completely cooled before maintenance, cleaning or storing.

Frame: Clean with mild soap and warm water. Do not use abrasive materials, cleaners or bleach. Rinse with clean water and dry thoroughly. NOTE: Discoloration to the finish can occur after repeated use.

Warranty

LIMITED 1 YEAR WARRANTY: The manufacturer will replace any part found to be defective in material or workmanship within 30 days of purchase date. The purchaser must contact the manufacturer's customer service department. After 30 days of purchase date the warranty is limited. The manufacturer, at its option, will repair or replace the parts.

WARRANTY REQUIREMENTS: Proof of purchase (dated register receipt) and photos are required for all warranty claims. It remains the customer's responsibility to pay for freight and packaging charges to and from the service center. The warranty is to the original purchaser and is non-transferable. Any replacement or warranted items will be in the original style and color, or similar style and color if the original is unavailable or has been discontinued. **Please contact our Customer Service for assembly assistance or replacement parts. Do not return to the store without authorization.**

WARRANTY EXCLUSIONS: Fire pits used for commercial, contract, or other non-residential purposes are excluded. Damage due to acts of nature, misuse, improper assembly or maintenance is excluded. Discoloration, fading, corrosion, and rusting are excluded.

LIABILITY: Inside Out Intl LLC and Retailer disclaim all liability for personal injury, property damage or loss resulting from incorrect assembly, improper use, inadequate maintenance, unapproved modification, or neglect of this product.

Customer Service Contact Information

Hours: Monday - Friday 8:00 a.m. - 5:00 p.m. Central Time (CT)

Phone: +1 (888) 607-4417

Email: service@shopfirehorse.com