
42IN Outdoor Kitchen Cook Station with Sink



Model: MC810SK
SKU: 40024

Your Satisfaction, Guaranteed.


We stand behind your purchase. If you experience any of the following, please contact us directly for a replacement:

- **Damaged items or parts (during transit)**
- **Defective or missing parts**
- **Assembly difficulties**


1-800-719-8199

service@nuukusa.com


Faucet Installation Instructions: Disassemble as shown in the diagram before installation



Drain Pipe System Assembly Instructions



42IN Outdoor Kitchen Cook Station with Sink



Model: MC810SK
SKU: 40024

NUUK USA
nuukusa.com

Table of Contents

It is the consumer's responsibility to see that theunit is properly assembled, installed, and maintained.

Table of Contents	- page 2
Safety Information	- page3
Customer Support	- page4
Care and Maintenance	
Exploded View	-page5
Parts	-page 6 - 7
Assembly Instructions	-page 7 - 18
Warranty	-page 19

Safety Information

To ensure your safety, we kindly remind customers of the importance in carefully assembling, installing and maintaining the product. Following the instructions in the manual diligently is crucial to prevent any potential risks of bodily harm or property damage.

- Not for permanent installation
- Suitable for outdoor use (or indoor)
- Only used on horizontal surfaces
- Maximum top/bottom weight load of 300 LBS
- Maximum middle shelf weight load of 200 LBS
- Maximum cabinet bottom weight load of 200 LBS
- Before use, make sure the height of the wheels is adjusted so that the table does not wobble while in use.
- Lock the wheels before use.
- Be careful with all electric appliances, tools, extension cords and lights on and around table.
- Surface will become hot in direct sun or high temperatures. Please touch carefully to avoid burns.
- Do not allow children to climb the product.

CALIFORNIA PROPOSITION 65 WARNING

WARNING: This product can expose you to lead,which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

Customer Support

HAVE PROBLEM / QUESTION / CONCERN
NO WORRY!

Our customer Service Staff is Here To Help You!

For questions rearding your NUUK prodcts, installation, replacement parts or your warrany, please contact

NUUK customer service team.

Phone: 1-800-719-8199
Monday through Friday
9:00 am to 5:00 pm, Eastern Time Zone

Email: service@nuukusa.com

Care and Maintenance

CLEANING


Painted and Plastic Surface
Wash with mild detergent or non-abrasive cleaner and wasm Water.

Stainless Steel Surface
Wash with mild detergent and warm soapy water or use stainless steel cleaner. Wipe dry with a spft cloth after tach use.

Wash only in the direction of the stainless brushed finish to avoid damage.

Stainless steel can rust under certain conditions. This can be caused by acidic marinades, chlorine, saltwater, exposure to coastal climates, other natural elements, or improper cleaning tools such as wire or steel wool.

Exploded View



When assembling, partially thread one screw into its corresponding position on one side, securing it temporarily (be careful not to fully tighten).

Proceed to do the same for the other locations following a similar approach until all screws for this step are correctly aligned with their threads.





Once this step is completed, proceed to fully tighten all screws.




If you encounter misalignment with any screws, gently apply manual pressure to slightly adjust the hole to align it with the desired position before threading the screw into the thread.

Once the screw is in place, release the pressure.


Following these steps will allow you to continue with the tightening process


Parts

PART	PIC	DESCRIPTION	QTY
1		Countertop	1
2		Sink	1
3		Middle Shelf Rail-L	1
4		Middle Shelf Rail-R	1
5		Middle Shelf	1
6		Side Handle	1
7		Shelf	2
8		Back Panel	2
9		Side Panel -Left	1
10		Side Panel -Right	1
11		Bottle Opener	1

PART	PIC	DESCRIPTION	QTY
12		Storage Rack	1
13		Support Bracket	2
14		Front Beam	1
15		Caster Wheel with Brakes	4
16		Front Door	1
17		Door Axle	1
18		Bottom Shelf	1
19		Faucet Inlet Hose	1
20		Middle Panel	1
21		Faucet	1
22		Faucet gasket	2



Parts

PART	PIC	DESCRIPTION	QTY
23		Faucet Nut	1
24		Water Storage Cover	1
25		Sink Screw	1
26		Stainless Steel Washer	1

PART	PIC	DESCRIPTION	QTY
27		Plastic Washer	2
28		Plastic Drain	1
29		Drain Pipe	1

Hardware and Assembly Instructions


Hardware

PART		DESCRIPTION	QTY
A		Bolt M6x12	82
C		Step Screw	3
E		Axle Holder	1
G		Door Magnet	1


PART		DESCRIPTION	QTY
B		Bolt M4x10	2
D		Flat Washer	2
F		M6 Step Screw	2

Assembly Instruction

A x 16 STEP 1



A x 2 STEP 2




NOTE:
Pay attention this slot on the bottom shelf

Assembly Instruction


A x 2

STEP 3




A x 2

STEP 4




A x 2

STEP 5



A x 2


STEP 6



Assembly Instruction


A x 2

STEP 7



A x 2


STEP 8



Assembly Instruction


A x 2

STEP 9




A x 2

STEP 10




A x 2


STEP 11



A x 4

STEP 12





STEP 13



F x 2




D x 2

STEP 14





B x 2




Assembly Instruction

STEP 15







STEP 1



STEP 4



STEP 2




STEP 3

Assembly Instruction


A x 4

STEP 16




A x 4

STEP 17




Assembly Instruction

STEP 18




A x 6

STEP 19



Assembly Instruction

STEP 20




STEP 1

STEP 2

A x 6


STEP 21



Assembly Instruction


A x 4

STEP 22



A x 2


STEP 23




Assembly Instruction

A x 5


STEP 24







A x 4

STEP 25






STEP 26




STEP 27




Assembly Instruction


STEP 28

A x 4







STEP 29




STEP 1



STEP 2




STEP 3



Refer to page#2 instruction detail


STEP 30

A x 2




STEP 31

C x 3



Assembly Instruction



FINISH PRODUCT

Warranty

NUUK LLC (NUUK USA)
1-YEAR WARRANTY

Proof of purchase is required to access this warranty program, which is in effect from the date of purchase.

NUUK USA warranty coves one year from the date of purchase. NUUK will assist you to get the replacement parts, replace the unit. ALL warranties are limited to the original purchase only. This warranty does not cover any liability for used good purchase. The purchaser must follow the usage instruction.

Warranty Provisions

· This warranty is non-transferable and does not cover failure due to misuse, improper installation or maintenance.
· This warranty is for replacement of defective parts only. We are not responsible for incidental or consequential damages or labor costs .
· This warranty does not cover damage caused by abrasive or chemical cleaners, or any damage to other components used in the installation or operation of the table.

· Paint is not warranted and may require touch-up.

NUUK customer service team

Phone: 1-800-719-8199
Monday through Friday
9:00 am to 5:00 pm, Eastern Time Zone

Email: service@nuukusa.com

NUUK USA
nuukusa.com