120mm

TRV 2PK UTV MIRROR LIGHT WITH AMBER

User Manual

120mm

120mm

120mm

INTENDED USE

TRAVELLER 2PK UTV MIRROR LIGHT WITH AMBER is designed to easily attach to light bars of UTV or 2 PORT PRO FIT or UNIVERSAL FIT brackets. The light is designed to be very low additional wiring. This rugged light features an IP68 weatherproof design. Constructed from high quality ABS plastic with a UV resistant finish. The light features a durable aluminum housing and has an left and right detachable multi-directional adjustable mounting bracket.

TECHNICAL SPECIFICATIONS

Item	Description
Voltage	DC 9V-36V
Beam Pattern	Flood
Product Size	Universal Fit Lower Light Bracket 10.6cm x 5.1cm x 6.35cm Pro Fit Lower Light Bracket 10.6cm x 5.27cm x 6.35cm
Watts	40W
Beam Distance	37ft ft (114 m)
Raw Lumen	5,400
Effective Lumen	2,200
Mount Type	Left and Right dedicated Indi-articulated (Polaris® Pro Fit and Universal Fit mounting brackets)

120mm

PARTS LIST

NO.	Description	Qty.
1	M8*30mm bolt	4
2	Spacer bushing	4
3	Universal Fit Lower Bracket (Left)	1
4	Universal Fit Lower mounting bracket (Right)	1
5	Universal Fit Lower Bracket (Right)	1
6	Universal Fit Lower mounting bracket (Left)	1
7	10-Universal Fit rubber spacer	2
8	1.5in Universal Fit rubber spacer	2
9	1.5in Universal Fit rubber spacer	2
10	M8 lock washer	4
11	M8*16mm bolt	4
12	Universal Fitmore pivot bolt	2
13	M8 bolt	2

Note: Universal Fit mounting brackets are optional.

120mm

PARTS LIST

NO.	Description	Qty.
14	M8*30mm bolt	4
15	Center hub	1
16	Pro Fit outer mounting bracket (Left)	1
17	Pro Fit outer mounting bracket (Right)	1
18	Pro Fit Lower Bracket	2
19	Pro Fit Lower Bracket	2
20	Pro Fit rubber spacer	2
21	Pro Fit rubber spacer	2
22	Pro Fit mounting bracket pad	2
23	Pro Fit mounting bracket pad	2
24	M8 nut	4
25	Washer	4

Note: Pro Fit mounting brackets are optional.

120mm

Mounting Instructions - Universal (Round Tube) Mounting Brackets

1. Remove inner mounting bracket Qty removing the retaining M8 nuts □ and bolts □ from the outside bracket □ using the Allen key.

2. Loosen center retaining bolt(M8*30mm) □ on the outside bracket □ (do not remove) to allow slight expansion of the outside bracket housing and the escentric adjustment ring.

120mm

3. Hold the inner assembly next to the desired mounting point on the vehicle. Ensure the bracket and mounting hardware (Qty.M8) are installed mounting angles are aligned.

4. Tighten the center retaining bolt(M8*30mm) □ while ensuring the locking teeth on the bracket and the escentric are aligned and locked.

5. Tighten the outside bracket □ (do not remove) to allow slight expansion of the bracket housing and the escentric adjustment ring.

Repeat operation for other side of vehicle.

120mm

Mounting Instructions - Polaris® Pro Fit Brackets.

1. Remove the inner mounting bracket Qty removing the retaining M8 nuts □ and bolts □ from the outside bracket □ using the Allen key.

2. Remove the center retaining bolt(M8*30mm) □and alignment ring □ on the outside bracket □ (keep these, you will need them later).

Repeat operation for other side of vehicle.

120mm

120mm

120mm

120mm

120mm

120mm

120mm

120mm

Mounting Instructions - Polaris® Pro Fit Brackets.

1. Remove the outside bracket □ from the desired mounting point on the vehicle. Ensure the bracket and mounting hardware (Qty.M8) are installed mounting angles are aligned.

2. Locate Polaris® Pro Fit bracket assembly. Remove the Pro Fit clamp by removing the two bolts □ and bolts □.

3. Place the assembly on the outside mounting bracket □.

4. Place the electrical wire through the outer mounting bracket □.
5. Place the Pro Fit clamp □ on to mounting bracket □ using the previously removed bolts(M8*30mm) □.
6. Place outer mounting bracket □ on to escentric adjustment ring ensuring the locking teeth are aligned and locked.
7. Remove the center retaining bolt(M8*30mm) □ and alignment ring □ on the outside bracket □ (keep these, you will need them later).
8. Tighten the center retaining bolt(M8*30mm) □ while ensuring the locking teeth on the bracket and the escentric are aligned and locked.
9. Tighten the outside bracket □ (do not remove) to allow slight expansion of the bracket housing and the escentric adjustment ring.
10. Place rubber isolator □ on to mounting bracket □ ensuring there is no contact between the outside bracket □ and escentric adjustment ring and the desired mounting angles are achieved.

120mm

11. Place outer mounting bracket □ on to escentric adjustment ring ensuring the locking teeth are aligned and locked.
12. Remove the center retaining bolt(M8*30mm) □ and alignment ring □ on the outside bracket □ (keep these, you will need them later).
13. Tighten the center retaining bolt(M8*30mm) □ while ensuring the locking teeth on the bracket and the escentric are aligned and locked.
14. Tighten the outside bracket □ (do not remove) to allow slight expansion of the bracket housing and the escentric adjustment ring.
15. Place rubber isolator □ on to mounting bracket □ ensuring there is no contact between the outside bracket □ and escentric adjustment ring and the desired mounting angles are achieved.

120mm

16. Ensure power cord is seated in the cutout provided on the bracket so it does not pinch anywhere on the vehicle.

17. Repeat operation for the other side of the vehicle.

120mm

INSTALL THE LIGHT

1. Connect the wire harness to the male connector.
2. Connect long lead (red) to Real battery positive (+) source.
Black cable to negative (-) power source.
Yellow cable to switched power.
When the switch press to "-" : the lamps ECO "ON".
When the switch press to "+" : the lights "OFF".
When the switch press to "+" : the lamps ECO "ON".

120mm

LIGHT BODY ADJUSTMENT

Mirror lights mounted on UTV cage with Escentric adjustment in maximum upward tilt position.

Mirror lights mounted on UTV cage with Escentric adjustment in maximum downward tilt position.

120mm

Adjust the tension for minut movement of light housing by unscrewing the cap to access the M8*15mm bolt.

MIRROR ADJUSTMENT

Remove the bottom of the glass mirror within the body by pressing on the corners of the mirror.

120mm

No user serviceable components inside.

Distributed by:
TRACTOR SUPPLY COMPANY
5401 Virginia Way
Brentwood, TN 37027
Tel: 1-800-275-2847
Fax: 1-800-10-2847
www.tractorsupply.com
MADE IN CHINA

120mm