



300 N. Oakley Blvd.
 Chicago, IL 60612 USA
 Phone 312-226-2473 FAX 312-226-2480
 Web www.bird-x.com E-mail sales@bird-x.com

BirdNet Instructions

HOW TO INSTALL: Each job is different and demands some on-site ingenuity. The four most common application techniques are pictured below.

<p>Wire and Polyclips Often used on concrete, brick or steel structures. Polyclips easily fold over wire and snap together through netting spacing 1' – 3' apart depending on job. Case of 250 Polyclips from Bird-X, part # MTG-CASE \$108.</p>	<p>Epoxy Caulk High quality epoxy caulk is readily available at local hardware stores and has been successfully used on concrete brick and steel. Or, Special Adhesive (for caulking gun) from Bird-X, part #SSA, 1 tube, \$8.</p>	<p>Plastic Band & Staples On wood structures a plastic banding has been manually woven into netting skipping every 4 or 5 strands. This allows stapling to a solid surface rather than a single netting strand.</p>	<p>Wood Lathe Strip Installations on wooden structures can easily be accomplished using wood lathe strips and nails.</p>

The Heavy-Duty Polyethylene netting is a Diamond shaped square cut mesh.

There is a piece of white string every 25 feet. Locate one ones that are the four corners.

How long will netting last? Once installed, durability will depend on the amount of exposure to sunlight. The netting is stabilized with chemical additives designed to give up to several years' effective life.

How do you cover widths wider than 50'? Jobs requiring wider widths can be easily handled by running a wire and using polyclips to fasten net to both sides, or by splicing net together manually using a high quality UV treated twine and a plastic needle.

Call us at 800-662-5021 if you need assistance installing the netting.