


Metal Garden Shed

Bicycle Storage

OWNER'S MANUAL

Instructions for Assembly



Size:L204 x W206 x H163cm
Size:L6.7 x W6.8 x H5.4 Feet

9820002-1
9820002-2

Require two people take at least 3-4 hours for installation.

Quick & Easy Assembly

Ridge Reinforced Walls

BEFORE YOU START

Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.


Assembly instructions

Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin. During assembly, follow the step sequence carefully for correct results. Please be aware: **this unit takes two people about one full day to complete.**

Parts


Check to be sure that you have all the necessary parts for the building. Separate contents of the carton by the part number while reviewing parts list. Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

TOOLS MAY REQUIRED



Use heavy duty gloves when handling steel sheets and flashing

PLAN AHEAD



Watch the weather:

Please be sure the day you select for installation is dry and calm.

DO NOT attempt to assemble your shed in windy weather because of risk of damage to panels, or personal injury. Be careful of wet or muddy ground.

Teamwork:

Whenever possible, two or more people should work together to assemble the building. One person can position parts or panels while the other is able to handle the fasteners and the tools.

PLAN AHEAD

Site Selection

- Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.
- Small trees, bushes or fences nearby can be helpful, acting as a wind break.

Site Preparation

The site must be prepared so that the base of the shed is level all round and checking with a spirit level is required.

The base can be constructed by treated timber or concrete, in order to stop the moisture getting into the shed. **The shed is not designed to be built onto lawn directly.** Also the ground will get muddy during rainy days.


If a concrete pad is made, it is important that this slopes towards the edges to prevent water ingress.

Time must be allowed for any concrete or cement to dry before building the shed on top.

Bases can also be constructed from bricks, blocks, or mounted on a concrete pad.

The bricks or blocks should be cemented onto firm and level concrete footings and the greenhouse frame drilled and screwed to the base.





















sharp edges



































Pay attention to the sharp edges. Please wear work gloves, long sleeves and eye glasses, when assembling or performing.
















IMPORTANT NOTES:



- Find someone to help you: it is much easier with someone to hold parts, pass tools ect. Also some steps require two people to lift structures together. This is not very heavy work so would suit most able-bodied people.
- Allow plenty of time: rushing often causes errors and the re-doing of incorrect assemblies. If you have never built a shed before, it can take most of a day to carefully complete the construction.
- Have the right tools to hand.
- Safety clothing as recommended in the 'Tools' section.
- Ideally lay out the parts and check that all are present before commencing construction. Lay on cloths or plastic sheets if there is any risk of scratching the parts.
- Tighten all nuts carefully, being sure not to miss any. Check the frame is square and using a spirit level to check that it is upright.





NO.	PART	Qty.
1	 1907mm/75.07"	2
2	 1907mm/75.07"	1
3	 1907mm/75.07"	1
4L	 1432mm/56.37"	1
4R	 1432mm/56.37"	1
6	 1895mm /74.6"	1
7L	 103mm/4.05"	1
7R	 103mm/4.05"	1
8	 1895mm /74.6"	1
9	 1895mm /74.6"	1
10	 1839mm/72.4"	2
13-1	 1567mm /61.69"	2
14	 1832mm/72.12"	2
15	 1855mm /73.03"	2
16	 605mm /23.81"	2
17	 605mm /23.81"	2
18	 745mm/29.33"	2
19	 745mm /29.33"	2
20	 130mm /5.11"	2
21	 130mm /5.11"	2


NO.	PART	Qty.
22	 90mm /3.54"	2
23	 4	
24L	 1	
24R	 1	
25L	 1	
25R	 1	
26	 1197mm/47.12"	1
26-1	 876 mm/34.48"	1
27	 1026mm/40.39"	4
26-3	 1197 mm /47.12"	1
26-4	 876 mm/34.48"	1
29	 4	
29-1	 4	
30	 855mm/33.66"	4
31	 1398mm/55.03"	1
32	 1398mm/55.03"	1
33	 1398mm/55.03"	1
34	 1398mm/55.03"	1
35	 955mm/37.59"	2
36	 955mm/37.59"	2

NO.	PART	Qty.
P1	 1400mm /55.11"	8
P2	 1400mm /55.11"	2
P3	 1567mm/61.69"	1
P4	 1567mm/61.69"	1
P5	 1567mm/61.69"	1
P6	 1567mm/61.69"	1
P7	 1567mm/61.69"	1
P8	 1036mm /40.78"	2
P9	 1036mm /40.78"	2
P10	 1036mm /40.78"	4
P11	 1036mm /40.78"	2
D1	 1388 mm /54.64"	2



NO.	PART	Qty.
J1		4
G6		2
G3		6
G7		1
G8		1
B5		2
GC		4
G2		2
F1	 #8AB-18x2/13	390
F2	  #8-32x2/13	50
F3	  #8-32x2/13	28
S2		170
S3		276






NO.	PART	Qty.	NO.	PART	Qty.
1		2	2		1
3		1	F1		8





Base Assembly



NO.	PART	Qty.
J1		4
F1		16




Anchor Installation








1、 When diagonal measurements are equal, the frame is square.

Inspection









2、 The Floor Frame must be BOTH square AND level or the holes will not line up properly.

NO.	PART	Qty.
4L		1
4R		1
F1		8
S3		6




Gate Post Installation








NO.	PART	Qty.
P2		1
P1		4
F1		17
S3		22
F2		5




Side Wall Panels Installation













NO.	PART	Qty.
13-1		1
F1		1
S3		2
F2		1










Corner Post Installation







NO.	PART	Qty.	NO.	PART	Qty.
P3		1	20		2
P4		1	21		2
P5		1	22		2
P6		1			
F1		20			
S3		20			




Bicycle Seat Holders Installation








Wall Panels Installation











NO.	PART	Qty.
P7		1
F1		17
S3		22
F2		5




The corrugation of next panel should cover that of the previous panel.









NO.	PART	Qty.	NO.	PART	Qty.
24L		1	7L		1
24R		1	7R		1
25L		1	G2		2
25R		1			
F1		4			
S3		4			
F2		8			






Triangle assembly and installation Vent installation




NO.	PART	Qty.
10		2
F1		36
S3		36



Left & right upper beams installation






NO.	PART	Qty.
6		1
F1		4









Girder Installation


NO.	PART	Qty.
8		1
F1		6
S3		6

Front upper beam installation







NO.	PART	Qty.	NO.	PART	Qty.
16		2	17		2
18		2	19		2

Studdle Preparation






x2

NO.	PART	Qty.	NO.	PART	Qty.
14		2	15		2





Bicycle Seat Preparation





NO.	PART	Qty.
23		4
F1		8







Bicycle Stopper Installation






NO.	PART	Qty.
F1		28

Bicycle Seat Installation





NO.	PART	Qty.
P8		1
P9		1
P10		2
P11		1
F1		19
S3		19











First Section of Roof

A side of all of the roof panels must be on upper direction;
B side of all of the roof panels must be on down direction.

A: short holes position apart from the edge
B: long holes position apart from the edge



NO.	PART	Qty.
P8		1
P9		1
P10		2
P11		1
F1		36
S3		36













Roof Installation


A: short holes position apart from the edge
B: long holes position apart from the edge

Second Section of Roof






B side of all of the roof panels must be on upper direction;
A side of all of the roof panels must be on down direction.







NO.	PART	Qty.	NO.	PART	Qty.
26		1	26-3		1
26-1		1	26-4		1
27		4	GC		4
F1		12			
S3		12			




Eaves and plastic connectors installation








NO.	PART	Qty.
29		4
29-1		4
30		4
F1		32


Left door frame assembly






x4


NO.	PART	Qty.
D1		1
31		1
32		1
S3		2
F2		2






Door panel D1 and frame assembly




NO.	PART	Qty.
F1		12
S3		14
F2		2

Left Door Assembly




NO.	PART	Qty.
G3		3
35		1
36		1
F1		16
F3		6

Reinforcement and hinges installation




NO.	PART	Qty.
D1		1
33		1
34		1
S3		2
F2		2

Right door assembly




NO.	PART	Qty.
F1		12
S3		14
F2		2




Right door assembly




NO.	PART	Qty.
G3		3
35		1
36		1
F1		16
F3		6


Reinforcement and hinges installation








NO.	PART	Qty.
G6		2
F1		8
F3		12



Door bolts and hinges installation



NO.	PART	Qty.	NO.	PART	Qty.
G7		1	B5		2
G8		1			
F2		10			



Doorknobs and lock installation

