

**DO NOT RETURN TO RETAILER
IF YOU HAVE ANY
QUESTIONS OR CONCERNS
PLEASE CALL
BOND MANUFACTURING
TOLL FREE AT
1-866-771-BOND(2663)
MONDAY – FRIDAY 8AM TO 4:30 PM PST
OR EMAIL TO
Customer.service@bondmfg.com
OR VISIT OUR WEBSITE ON
www.bondmfg.com**

Assembly Instructions

Item#: Y94169

**** WARNING ****

Read these instructions carefully and keep the fountain power off until the following assembly process is strictly completed.

Notes:

- Choose an appropriate location for the fountain.
- Excessive weight or pressure on any of the fountain sections may cause it to fall. Keep pets, children, or anyone from sitting, leaning, or climbing on any of the fountain components.
- While fountain is designed to operate as splash free as possible, some water splashing out of the fountain is inevitable. Place the fountain in a location where any splashing will not cause damage.
- The National Electric Code requires that a ground fault circuit interrupter (GFCI) be used in the branch circuit supplying fountain pump and other pond equipment. Seek your electrical supplies dealer for this device.
- Always keep the fountain working with sufficient water and clean of debris and dirt to ensure proper functioning of the pump.
- If necessary, clean the fountain with a soft cloth and change the water frequently. Due to water evaporation, you may see a buildup of white residue on the fountain surface from mineral content in the water supply. To prevent such buildup, regularly clean the fountain with soap and water, do not use any abrasive, which may damage the applied finish.
- **Use of water clarifier, or algicide of any kind will damage the paint on the fountain and will not be covered under the manufactures warranty.**
- See the pump instructions for pump safety, maintenance, and warranty information.
- Keep this manual for future reference.

Installation & Assembly

- Place the fountain on a level surface, away from areas where it is likely to get clogged with leaves and make sure that the cable will reach the socket.
- Take out all the packaged parts from the carton
- Follow steps to assemble as illustrated below

Step (1). Pull out the flexible hose from the back door- " location ① " of the fountain, then connect it to pump outlet, showed as ②

Step (2). Pull out the cable line of the light from the back door " location ① " of the fountain, then connect the connector of LED light to the adaptor, showed as ③

Step (3). Closed up the back cover to the fountain as showed ④ in Figure `1`.

Figure `2`

Fill the reservoir with clean water carefully. Always make sure the water can submerge the pump completely to work properly and prevent the pump damage.

Plug the pump and adaptor then switch on, the water will start to flow in minutes, and lights will be shining instantly.

- Adjust the pump flow rate to achieve the desired effect and to minimize any splashing, showed as **(F)**. Splashing can occur if the flow rate is too high or the reservoir is too full. The flow rate can be increased or decreased by moving the flow rate control slider on the pump body. Moving the slider towards `+/ Max.` will increase the flow rate and moving it towards `-/Min` will decrease it. On some type of pumps, flow regulator may be turned clockwise or counterclockwise to adjust.




Fig.1







Fig.2



-  Clockwise Full Flow
-  Counterclockwise reduced Flow

Troubleshooting

- - TURN OFF THE POWER BEFORE YOU CHECK THE FOLLOWING - -

If pump does not run, or lights are not on --

- (1) Check the circuit breaker, try another outlet.
- (2) Check the water level in the fountain. Running the pump without sufficient water can damage the pump.
- (3) Check the setting of the flow control on the pump and adjust the flow.
- (4) Check the pump discharge and intake for dirt and debris.
- (5) Check the fountain for kinks and obstructions.
- (6) The pump might be "air locked". Plug and unplug the pump several times to release the air inside the pump.
- (7) Check and reconnect the cord and try again.

IF YOU HAVE QUESTIONS OR CONCERNS

PLEASE CALL BOND TOLL FREE #

1-866-771-BOND(2663) OR TO BETTER

EXPEDITE YOUR REQUEST FEEL FREE TO EMAIL US

Customer.service@bondmfg.com

OR LOG IN TO OUR WEBSITE UNDER CUSTOMER SERVICE SUPPORT

www.bondmfg.com