

**Authentic Country Living** 



## IMPORTANT: READ CAREFULLY BEFORE BEGINNING!

- Make sure that all parts and hardware are present before assembly.
- Assemble on a non-marring and level surface
- Do not completely fighten all nuts and bolts until the bench is fully assembled.


# WINDMILL 9FT. TRIPOD TEXAS FLAG

ITEM #: TX 93480

PARTS AND HARDWARE LIST		
A	В	С
Windmitt Legs  A1 (TOP) = 3PCS  A2 (BOTTOM) = 3PCS	Top Mount Platform	Side Panels
	B = 1PC	C = 3PCS
D	E	F
Star Ptatform මාමයෙක් ලාලාලාලාලා D = 1PC	Decor Cap  E = 1PC	Meedte (Screw into B)  F = 1PC
G H I	J	K
Windmitt Head  G = 1PC Rudder H = 1PC Fan Blades I = 1PC Stop Nut	Screws  N4 X 0.4"  J = 9PCS	M6 X 1.8" K = 6PCS
Tools Required for Assembly: #2 Phillips Screwdriver 10" Adjustable Wrench		Ground Stakes L = 3PCS


## STEP 1

Secure the Needle (F) into the Top Mount Platform (B).
Secure the Top Mount Platform (B) to the top of the Leys
(A1) with the Screws (J). Connect top portion of Leys
(A1) to the bottom part (A2). Ley should face inwards.




### STEP 2

Affix the Side Panel (C) into place between the Windmill Legs (A), tighten with the Bolt & Nut (K).



## STEP 3

Affix the StarPtatform (D) on top of the Windmitt Legs (A), and tighten with the Screws (J).



#### STEP 4


Ptace the Directional Cap (E) on the Top Mount Ptatform (B), tock into ptace with the Needte (F).



#### STEP !


Assemble the Windmill Head (G, H, I), make sure the Stop Nut (I) is screwed on well.

Mote: The front hole of the Fan Blades (H) is larger than the back hole.



#### STEP

Ptace the Windmitt Head (G,H,I) on the Needte (F). Secure the Windmitt by inserting the Ground Stakes (L) through each hote at the base of each tegs.



# Limited Warranty and Care Instructions

# LIMITED ONE YEAR WARRANTY (NON-TRANSFERABLE)

This product is covered under United General Supply's (UGS) one (1) year limited warranty. To the original purchaser of this piece of furniture, cooler or accessory; UGS warrants that it will be free from defects in material and workmanship for up to one year from the date of purchase under normal use and proper care.

Replacement of defective or missing parts will be sent at no charge to the customer for a period of 30 days from the date of purchase. UGS will no longer be responsible for missing parts or hardware 30 days after date of purchase. Freight, packaging, labor or material charges to and from our customer service center is not covered under the warranty and is therefore the customer's responsibility.

The limited warranty does not cover this piece of furniture, cooler or accessory for commercial purposes, abusive use, damage by modification, freeze damage, rust, fading and issues caused by improper care.

For minor defects or missing parts/hardware, please contact customer service immediately upon purchase. Please do not return product to the store unless the product is irreparable. A customer service agent may help determine whether the damage is reparable and will provide further instructions.

For returns and refunds, please refer to your local store return policy with proof of purchase.

Proof of purchase (dated register receipt) will be required for warranty claims.

# **Proper Care Instructions**

To clean the bench, use a mild soap and rinse with water. Dry off the bench completely with a soft cloth. Durning a long periods of non-use, store furniture in the covered and dry place. For the least maintenance, use under covered area.

Proof of purchase (dated register receipt) will be required for warranty claims. For faster service, please email proof of purchase and photos to help@ugsco.com.

Customer Service may be reached Monday through Friday from 9:00a.m. to 5:00p.m. CST.

HELPaugsco.com or 1-877-87Leight (53444)



DISTRIBUTED BY:

UNITED GENERAL SUPPLY CO., INC.

HOUSTON, TX 77036

www.LeighCountry.com