



Instant Pop Up Canopy Instructions




(1) Take the frame out from the roller bag and stand it up in the middle of the area where shade is desired. (2) With someone at the opposite corner, slowly open the tent by grasping the legs and lifting the canopy slightly off the ground, pulling the legs away from each other.




(5) Go to opposite ends of the canopy and grasp the frame (either at the legs or at the center lower V section of the truss bars) and step backwards opening the frame up completely. (6) As you get the frame to the full open stage, fold the cover's valances up at the corners slightly and use one hand to push up on the leg slider while holding the leg with the other hand. Push the slider up until you hear it lock in place. Repeat with the other 3 legs. **KEEP FINGERS AWAY FROM SLIDING PARTS TO AVOID PINCHING THEM.**




(7) Pull the cover back down at each corner and adjust so that it fits snugly and does not sag. (8) Lastly - both persons go to the side of the canopy and extend the legs by placing your foot on the footpad and lifting the upper part of the canopy at the legs with your hands until the legs lock in place. Repeat on the other side. Lastly, adjust to desired height and secure with stakes or weight bags at the legs if needed.




Folding The Cover




With 1 person holding the peak, person 2 follows the seam to one of the corners.



While holding valance corner in one hand, person 2 now grabs the next valance corner and with the other hand folds it together with the first corner. Repeat for the rest of the corners.



After having the top folded in a triangle shape, take the valance corners and fold over as shown above. Next take the peak corner and fold down into a rectangle shape.



Fold cover over about 5 or 6 times in increments of 6 to 8 inches so that it may be put away inside the pocket or inside along with the frame depending on the style of bag with your canopy.