



Instant Pop Up Canopy Instructions



(1) Take the frame out from the roller bag and stand it up in the middle of the area where shade is desired. (2) With someone at the opposite corner, slowly open the tent by grasping the legs and lifting the canopy slightly off the ground, pulling the legs away from each other.




(5) Go to opposite ends of the canopy and grasp the frame (either at the legs or at the center lower V section of the truss bars) and step backwards opening the frame up completely. (6) As you get the frame to the full open stage, fold the cover's valances up at the corners slightly and use one hand to push up on the leg slider while holding the leg with the other hand. Push the slider up until you hear it lock in place. Repeat with the other 3 legs. **KEEP FINGERS AWAY FROM SLIDING PARTS TO AVOID PINCHING THEM.**




(7) Pull the cover back down at each corner and adjust so that it fits snugly and does not sag. (8) Lastly - both persons go to the side of the canopy and extend the legs by placing your foot on the footpad and lifting the upper part of the canopy at the legs with your hands until the legs lock in place. Repeat on the other side. Lastly, adjust to desired height and secure with stakes or weight bags at the legs if needed.




Folding The Cover




With 1 person holding the peak, person 2 follows the seam to one of the corners.



While holding valance corner in one hand, person 2 now grabs the next valance corner and with the other hand folds it together with the first corner. Repeat for the rest of the corners.



After having the top folded in a triangle shape, take the valance corners and fold over as shown above. Next take the peak corner and fold down into a rectangle shape.



Fold cover over about 5 or 6 times in increments of 6 to 8 inches so that it may be put away inside the pocket or inside along with the frame depending on the style of bag with your canopy.



WARRANTY INFO

Missing/Defective Parts

We try our best to eliminate any defective parts that are shipped with our products. Carefully inspect all packages upon arrival and report any missing or defective items upon receipt. Any discrepancies must be reported to King Canopy within 30 days of purchase. Please be sure to take a few minutes to match all items in the box to the items on the product manual. If there should be any missing or defective items, we will ship them free of charge. You will need to fill out a warranty claim form and e-mail, fax, or mail it in along with a proof of purchase showing date of purchase. Your replacement will be shipped free of charge by ground shipping. Next day or express shipping will require freight collect and paid for by you. Damages from improper anchoring, strong winds, snow, ice or rain are not considered defects.

1 Year Limited Warranty

All of our canopy components feature a 1-year limited warranty (90 day-limited on Value King Brand items) and are warranted to be free from defects in material and workmanship during this time frame. You must fill out our warranty claim form and provide your proof of purchase receipt. This does not pertain to any missing or defective parts in the 30 day inspection period.

Defective Returns

If you receive a product that is defective and wish to return it, please contact our customer service department to receive a return authorization number. All items will be passed through quality control before issuing a credit. You will be contacted upon receipt of your returned merchandise and notified whether your return is accepted or not. If not, you will have the option to receive the product back at your expense.

Improper Anchoring, Strong Winds, Rain, Snow, or Ice

King Canopy/ PIC America, LTD. does not guarantee these canopies under strong weather conditions (including snow and ice) under any circumstances. These canopies are designed to protect against damages cause by sun, light rain, tree sap, birds, etc. They are not designed to hold roof loads that accompany snow, ice, or heavy rains. If your canopy is not anchored securely, strong winds can lift it and cause damage if it is blown over and/or away. Canopies make excellent kites. If your canopy is anchored incorrectly and is blown away, we will not send any free replacement parts for damages. If you know strong weather is predicted, remove the cover or take down the unit completely. The cover is designed to be quickly and easily removed.

Non-Warranty Replacement Parts

If your warranty expires and you need replacement parts and they cannot be found on www.kingcanopy.com, please contact us at 1-800-800-6296. We stock replacement parts for most of our products. Our customer service department will be pleased to assist you in any way possible.

Certain regions of the country are extremely harsh on canopy covers. Normal wear and tear is not covered under warranty, and should be expected.

In order to receive a discounted or free replacement part, you may be asked to return the part, freight prepaid, to our warehouse for inspection before we will send a replacement. You must, in all cases, provide a copy of your receipt showing the date of purchase, model number and price.

Customer Service:

8:00 AM – 5:00 PM EST, Monday - Friday
1-919-552-2977 • Toll Free: 1-800-800-6296 • Fax: 1-919-552-5069

Return Policy

All returns will require a return authorization number (RA). To obtain an RA, please contact our customer service department at (800) 800-6296. All returns must be submitted within 30 days of purchase date, located on receipt. Any returns submitted after 30 days without an RA number will not be accepted. Credit will be issued upon receipt of product and inspected for damages or excessive wear and tear. The full amount of the product will be credited in the form of original payment minus a 15% restocking fee and shipping and handling.

Please allow time to inspect and issue the appropriate refund.

Customer Service:

8:00 AM – 5:00 PM EST, Monday - Friday
1-919-552-2977 • Toll Free: 1-800-800-6296 • Fax: 1-919-552-5069
returns@kingcanopy.com

SAFETY AND CARE INFORMATION

- 1 Always use common sense.
- 2 Do not use your canopy as a permanent cover.
- 3 It is designed for temporary use only. Damages due to weather conditions are not warranted.
- 4 Do not set up on a steep incline. Do not leave unattended.
- 5 Never set up in windy, rainy, or snowy conditions. Canopy is not intended to serve as protection from such conditions. Use for shade only. Disassemble and properly store your Canopy after each use.
- 6 Do not let snow or rain accumulate on top. It will collapse.
- 7 Always use an anchoring system. Your canopy will take flight in windy conditions. Anchoring is your responsibility. Damage due to weather conditions are not warranted.
- 8 Keep your canopy away from all fire sources, such as grills or fire pits.
- 9 Do not machine wash your top. Wash with mild soap and water with a brush while the Instant Canopy is open without the legs extended. Do not use harsh detergents, abrasives or bleach.
- 10 Do not put your Instant Canopy away while wet or damp. This promotes mildew and rust. Always store completely dry.
- 11 For best results in keeping your top clean and to avoid small rips and tears, it is recommended that the top be removed and stored in the carry bag after each use.
- 12 **Never leave your canopy unattended!**

WARNING!

Keep all flame and heat sources away from this tent fabric. This tent is made with fabric that meets CPAI-84 Section 6 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source.