

WARNING: Be safe. Always wear a helmet and other protective gear.

WARRANTY

Flybar warrants the original purchaser, that the product is free of defects in material and workmanship for a period of one year from the original date of purchase. This warranty does not apply to defects of physical damage resulting from abuse, neglect, improper repair, improper fit, alterations or use unintended by the manufacturer. If your Flybar product is found to be defective in materials or workmanship within one year from the date of purchase, Flybar will, at its discretion, either repair or replace the product free of charge. Proof of purchase is required. Go to www.flybar.com for complete warranty information.

ABOUT US

In 1918 George Hansburg introduced the pogo stick and opened the original pogo stick company. Soon after, Hansburg brought his pogo to personal friend, Florenz Ziegfeld of the world-famous Ziegfeld Follies. Ziegfeld, the eminent Broadway impresario of the day, immediately choreographed a pogo routine into his show. The Follies made pogo sticks the latest craze. Hansburg made the pogo stick his passion and never stopped innovating in pogos.

From innovating the extreme pogo, introducing interactivity, to continuously supporting pogo sports and pogo health all around the globe, Flybar continues to be the world's leading pogo stick company. But Flybar today is not just pogos. New products for toddlers, stilts, gear and skateboards are all designed and developed with the passion and innovation Flybar customers expect.

Flybar, Since 1918.



Flybar, Inc, Ellenville NY 12428
All Rights Reserved. 2017
www.flybar.com



Pogo Trick Board

OWNER'S MANUAL

FOR AGES 6+
Max weight 160lbs

FBTB-P
FBTB-G
FBTB-R
FBTB-B
FBTB-PU

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR POGO TRICK BOARD. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

ALWAYS USE IN FRONT OF ADULT SUPERVISION

ALWAYS ADHERE TO THE BELOW AGE AND WEIGHT RESTRICTIONS:

POGO TRICK BOARD - FOR AGES 6+, Max weight 160lbs.

SAFETY



Using your Pogo Trick Board safely is mostly common sense.

- **Check your ball & board** to insure it is in good condition. The ball should be filled to your preference.
- **Check for hazards before you start.** Never jump without first making sure that the surface is safe—solid, flat, clean, well lit and dry. The Pogo Trick Board will bounce on almost any indoor surface but give yourself plenty of room to maneuver. When playing outdoors, stick to areas free of hazards and steer clear of streets, parking lots and other areas vehicles use.

- **Slippery/Uneven Ground:** Don't try to jump on a surface which is wet, oily or even lightly covered with sand, gravel, leaves or litter—you'll greatly increase the chance of damaging the ball and possibly yourself.

**WEAR A HELMET! ESPECIALLY IF YOU ADVANCE TO DOING TRICKS.
ALWAYS WEAR ATHLETIC FOOTWEAR.**

ASSEMBLY:

1. The Pogo Trick Board comes with a hand pump to inflate the bounce ball. Adult inflation is recommended.
2. Securely attach the air needle to the end of the hand pump.
3. Insert deflated ball in the opening of the board. The Flybar logo and air hole on the bounce ball must be on top.
4. Insert the needle, firmly and straight into the ball's air hole. Be sure to press all the way down.
5. As you pump, and the ball takes shape, ensure the ball lip is below the deck edge. Use the ball guide included in the packaging to show the maximum inflate size for the bounce ball.

Note:

- Keep the air pump, handy. Bounce balls loose air overtime. Before each use, ensure the bounce ball is filled to your preference.
- The less air in the ball the easier it is to control the Pogo Trick Board. More air in the ball will give you bigger jumps but makes it harder to balance.
- The air pump handle has a secret compartment to stash your extra air needle.
- Keep the ball and deck clean by wiping with a damp cloth.

Helpful Instructions For Use:

3 easy steps to get you bouncing on the Pogo Trick Board:

1. Start by placing just one foot on one side of the board, with the inside of your foot pressing into the ball. One edge of the board should be resting on the ground.
2. Bring your other foot to the other side of the ball, but don't press your weight down all at once. Instead, practice see-sawing on the board as you get used to squeezing the ball with both feet.
3. When you are comfortable balancing and squeezing the ball between your feet, try taking a hop or two.

4 Basic Tricks:

1. Spin around as you bounce.
2. Bounce long distances in a forward direction down a path.
3. Bounce and in mid-air bend your knees. Land on board and continue bouncing.
4. As you bounce, swing your feet to one side and touch the board.

Show us what other tricks you can do on the Flybar YouTube channel.

