


# WEB SWING

MODEL # WS-39BLK



## TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Rope might become tangled.	While storing swing, the seat can become tangled due to the nature of the rope.	Please inspect the swing before hanging. Ensure that all rope is free of any knots or tangles.

## CARE AND MAINTENANCE

- Store in a dry and clean place when not in use, especially during periods of bad weather and in climates prone to harsh conditions.
- To clean, stretch out on a clean, dry, non-abrasive surface. Wet with a hose and gently scrub with a soft brush and mild soap-water solution. Rinse the item thoroughly and allow it to dry completely before using it again or storing it.

## WARRANTY

1-YEAR LIMITED WARRANTY: Product is guaranteed free of defects in workmanship and materials for up to one year from the date of purchase. If product is found to be defective within that time, the manufacturer will replace it at no charge. Normal wear and tear, including prolonged exposure to snow, rain and heavy humidity, is not covered, nor is mold, mildew or damage from improper storage, maintenance, installation, or acts of God. Call us toll-free at (252) 758-0641.

## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

**NO TOOLS REQUIRED**


## SAFETY INFORMATION

### WARNING

- Read all instructions carefully and completely before assembly and use. Retain for future reference.
- Keep plastic bags and small parts away from children.
- This swing is designed for 1 person maximum with a weight limit of 600 lbs. Exceeding load capacity can result in serious injury. In addition to the swing, check load capacity of any stand or hardware supplied by the user.
- Hang from stable and secure location that can accommodate the weight of the swing and user.
- For residential (non-commercial) use only.
- DO NOT use swing near stairs, water, or fire pits.
- DO NOT allow children to use swing without adult supervision.
- DO NOT stand on swing. DO NOT jump into swing.
- DO NOT bounce or swing aggressively.
- Before each use and after moving unit, always check swing to:
  - Ensure hardware remains tight. Re-tighten loose hardware as necessary.
  - Ensure all rope is free of fraying, tears, or any other damage.
  - Ensure no components are worn, corroded or damaged. DO NOT use swing until damaged components are repaired or replaced.

## PACKAGE CONTENTS


A



x 1

## HARDWARE CONTENTS


AA



x 2

## INSTALLATION OVERVIEW


1



Use carbiners to hang swing on your choice of stand or suspension ceiling hook. Stand and ceiling hook sold separately.

## INSTALLATION OVERVIEW

2



! Make sure the seating height is set to a comfortable level that makes it easy and safe to get in and out of.