




ITEM:10102163

STEEL MESH LOADING RAMP



TECHNICAL SPECIFICATIONS

Rated Capacity	800 lbs. distributed load and 1600 lbs. when using 2 ramps
Ramp Dimensions	80 in. Long x 11in. Wide

SAFETY

WARNING! Read and understand all instructions before using this device. The operator must follow basic precautions to reduce the risk of personal injury and/or damage to the equipment.

Keep this manual for safety warnings, precautions, operating or inspection and maintenance instructions.

WORK AREA

1. Operate in a safe work environment. Keep your work area clean, well-lit and free of distractions. Place lights when you are working in the dark.
2. Keep anyone not wearing the appropriate safety equipment away from the work area.
3. Store devices properly in a safe and dry location. Keep devices out of the reach of children.

PERSONAL SAFETY

WARNING! Wear personal protective equipment approved by the Canadian Standards Association (CSA) or American National Standards Institute (ANSI).

PERSONAL PROTECTIVE EQUIPMENT

1. Always wear impact safety goggles that provide front and side protection for the eyes. Eye protection equipment should comply with CSA Z94.3-07 or ANSI Z87.1 standards based on the type of work performed.
2. Wear protective clothing designed for the work environment and device.
3. Non-skid footwear is recommended to maintain footing and balance in the work environment.
4. Wear steel toe footwear or steel toe caps to prevent a foot injury from falling objects.

PERSONAL PRECAUTIONS

1. Do not operate any device when tired or under the influence of drugs, alcohol or medications.
2. Do not overreach when operating the device. Proper footing and balance enables better control in unexpected situations.

SPECIFIC SAFETY PRECAUTIONS

WARNING! DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to the device safety rules. If you use this device unsafely or incorrectly, you can suffer serious personal injury.

1. Use the correct device for the job. This device was designed for a specific function. Do not modify or alter this device or use it for an unintended purpose
2. Do not use the device if any parts are damaged, broken or misplaced. Repair or replace the parts.
3. Remove a pick-up truck's tailgate before placing the ramps in position. The tailgate may fail under the load's weight, causing the load to fall, resulting a serious injury.
4. The ramp's maximum installed height must not exceed 30 inches as the incline is too steep to safely load or unload a machine.

5. Always use safety straps to securely fasten the ramps to the vehicle. Straps will help to prevent the ramps from slipping off the vehicle.
6. Do not exceed the ramp's maximum weight capacity.
7. Avoid dynamic loading. Sudden load movement may exceed the load capacity and break the ramps.
8. Engage the vehicle's parking brake, place chocks under the wheels and turn the engine off while loading or unloading.

UNPACKING

WARNING! Do not operate the device if any part is missing. Replace the missing part before operating. Failure to do so could result in a malfunction and personal injury.

ASSEMBLY & INSTALLATION

1. Clean each ramp's surface of dirt and oil. Dry the ramps to eliminate a slick surface.
2. Park the carrying vehicle or trailer on a flat surface capable of supporting the load. Engage the parking brake and turn the engine off.
3. Place each ramp on the back of the truck or trailer so the plate has solid contact with the truck/trailer bed. Make sure the ramps align with the load's wheels.
 - 3.1 Remove the tailgate from a pickup truck for safety.
4. Secure each ramp with a safety strap. Wrap the strap around a rung. Slide the hook through the strap's loop and tighten it.
 - 4.1 Place the hook on a solid part of the vehicle's frame.
 - 4.2 Tighten the strap to secure the ramp. Test the ramps by pulling backward on it. Ensure the safety strap does not allow rearward movement of the loading ramps.

OPERATION

WARNING! Do not ride your machine up or down the ramps as you may injure yourself or a bystander if the ramps collapse due to the additional weight or you lose control of the machine.

1. Align the machine's tires with the ramps.
2. Having one person on each side of the machine when loading or unloading is preferred.
3. Use the brakes to control the machine while it is on the ramps. If the engine is running, have it in the lowest gear possible.


CARE & MAINTENANCE

WARNING! Only qualified service personnel should repair the device. An improperly repaired device may present a hazard to the user and/or others.

1. Maintain the device with care. A device in good condition is efficient, easier to control and will have fewer problems.
2. Inspect the device components periodically. Repair or replace damaged or worn components. Only use identical replacement parts when servicing.
3. Maintain the device's labels and name plates. These carry important information. If unreadable or missing, contact Canadian Tire for replacements.



RIGHT



WRONG WAY

