

pore
enrichment

5 YEAR
WARRANTY

weighted warmth™
XL WEIGHTED PAD



USER MANUAL
MODEL: PEWTPLRG

WARNINGS AND PRECAUTIONS



NON-OBSERVANCE OF THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY OR MATERIAL DAMAGE (ELECTRIC SHOCK, SKIN BURNS, FIRE).

THE FOLLOWING SAFETY AND HAZARD INFORMATION IS NOT ONLY INTENDED TO PROTECT YOUR HEALTH AND THE HEALTH OF OTHERS, IT SHOULD ALSO PROTECT THE PRODUCT. FOR THIS REASON, PAY ATTENTION TO THESE SAFETY NOTES AND INCLUDE THESE INSTRUCTIONS WHEN HANDING OVER THE PRODUCT TO OTHERS.

1. Read all instructions.
2. The weighted pad must not be used by people who are insensitive to heat or by impaired people who are unable to recognize if the product is overheating and needs to be turned off.
3. The weighted pad may not be used by very young children (0-3 years old) as they are unable to respond to overheating.
4. The weighted pad may not be used by young children (3-8 years old) unless the controller has been set by a parent or a responsible adult and the child has been given adequate instructions on how to use the pad safely.
5. This pad may be used by children over the age of 8 and by people with reduced physical, sensory or mental skills or a lack of experience or knowledge, provided that they are supervised and have been instructed on to use the pad safely, and are fully aware of the consequent risks of use.
6. This is NOT A TOY! Children must not play with the weighted pad.
7. Cleaning and user maintenance must not be performed by children unless supervised.
8. This weighted pad is not designed for use in hospitals.

WARNINGS AND PRECAUTIONS

9. Do not insert needles into the weighted pad.
10. Do not use when folded or bunched up.
11. Do not use if wet.
12. This weighted pad may only be used in conjunction with the provided adapter.
13. The electrical and magnetic fields emitted by this pad may interfere with the function of a pacemaker. However, they are still well below the limits: max. 5000V/m, magnetic field strength: max 80a/m, magnetic flux density: max. 0.1Mt. Please consult your doctor and your pacemaker manufacturer before using this pad.
14. Do not pull, twist or make sharp bends in the cables.
15. Carefully examine the pad frequently for signs of wear and tear or damage. If you detect signs of damage, it must be inspected by the manufacturer before turning it on again.
16. If the cables of the pad or the charger are damaged, they must be replaced by the manufacturer, its customer service department or similarly qualified person to avoid any risk.
17. When pad is switched on do not place any products on top of it including heating sources, such as hot water bottles, or heating wraps.
18. Save these instructions.

INTENDED USE IMPORTANT

This weighted pad is only designed to warm up and relax the human body.

INTRODUCTION

Thank you for purchasing the WeightedWarmth™ XL Weighted Pad from Pure Enrichment. Our unique line of weighted pads are available in regular (20" x 12") and extra-large (32" x 21") sizes. They combine weighted pressure and gentle heat into one deluxe pad that can be used on your lap, back, chest, and shoulders.

PRODUCT FEATURES

We designed this XL weighted pad with several features that make it the ideal solution for comfortable daily use. These features include:



WEIGHTED PRESSURE

Offers calming comfort to soothe the body and promote relaxation.



3 HEAT SETTINGS

Choose from low, medium, or high heat settings.



DIAMOND QUILTING

Ensures even distribution of warmth and weight.



SUPER SOFT

Luxurious and plush micromink fabric.



AUTO SHUT-OFF

Conserves energy by turning off after 1 hour.



EXTRA-LONG CORD

5'9" long cord allows you to use the blanket anywhere.



TRAVEL FRIENDLY

Transports easily to school, work, or on vacation.

USING THE XL WEIGHTED PAD

To turn on the heat

- Press the power button. The pad will automatically set to the high temperature setting and the red LED light will remain on.
- For maximum warmth, make sure the smooth side of the pad (without diamond quilting) is touching your body. The heated coils are located on that side.

To lower the heat setting

- Press the power button a 2nd time to switch to the medium setting. The LED light will turn white on the medium setting.
- Press the power button a 3rd time to switch to the low setting. The LED light will turn blue on the low setting.

To turn off the weighted pad

- Press the power button a 4th time.
- The LED light will turn off.

To use as a weighted pad

- Disconnect the unit from the adapter.
- Store the adapter in the zippered pocket on the weighted pad.
- Place the weighted pad on your lap, back, chest, shoulders, or other areas as needed.

SAFETY ALERT: The weighted pad is fitted with a Safety Thermal Switch. A sensor prevents the pad from overheating by automatically switching it off when the maximum temperature is reached.

NOTE: The pad will turn off automatically after 1-hour of heating use. It can be turned back on by pressing and holding the power button for about 3 seconds.

WARNING: If you will be using the weighted pad for several hours, we recommend setting it to the lowest temperature setting to avoid overheating the body, which may lead to skin burns.

CLEANING INSTRUCTIONS

To prolong the life of your weighted pad, occasional spot cleaning may be necessary. Follow these instructions to preserve the softness of the fabric and protect the electrical components:

1. Prepare a cleaning solution with 1 cup lukewarm water and 1/4 tsp mild detergent.
2. Dip a clean cloth into the cleaning solution and use circular and diagonal motions to remove the stain.
3. Rinse the cloth with water to remove any detergent and use the rinsed cloth to remove any remaining cleaner from the weighted pad.
4. Allow the treated area to air dry before use.
5. DO NOT machine wash.
6. DO NOT allow electrical components to get wet.

PRODUCT SPECIFICATIONS

Pad Size:	Regular (20" x 12") Extra-Large (32" x 21")
Power Supply:	Regular: 12V, 50/60Hz, 24W Extra-Large: 12V, 50/60Hz, 36W
Weight:	Regular: 2 lbs Extra-Large: 6 lbs
Material:	Micromink Velvet
Auto Shut-Off Timer:	60 minutes
Heat Settings:	Low-temperature range (~113°F) Medium-temperature range (~122°F) High-temperature range (~131°F)

WARRANTY

WeightedWarmth™ comes with an industry-leading 5 Year Warranty that begins on the date of purchase.

The warranty applies to the weighted pad and necessary parts and labor relating thereto. The warranty does not apply to damage resulting from failure to follow the operating instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

PRODUCT REGISTRATION

To ensure your full warranty and to receive product updates and streamlined customer support, remember to register your product at:

pureenrichment.com/productregistration

ARE YOU 100% SATISFIED?

If you have product questions or concerns, don't hesitate to contact us directly at:

Email: help@pureenrichment.com
Phone: (657) 275-3737
(Available Monday-Friday, 8am-5pm PST)

Pure Enrichment has an award-winning warranty, exchange, and customer service program that guarantees hassle-free solutions to any issue you might have within 24 hours!

FCC NOTICE

Model: WeightedWarmth™ XL Weighted Pad (PEWTPLRG)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pure Enrichment
2803 S. Yale St.
Santa Ana, CA 92704
pureenrichment.com

The product is protected against unauthorized use. DO NOT modify it without the authorization of the manufacturer, or the user's authority to operate could be voided.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Santa Ana, CA 92704
pureenrichment.com