

Thank you for purchasing a **K&H CleanFlow™** filtering water bowl. With proper care and cleaning, your CleanFlow™ should offer years of hassle free water filtering service for your pets.

### USE INSTRUCTIONS

Read all instructions carefully.

#### OPERATING INSTRUCTIONS:

- 1** Remove the lid or reservoir from the pump/filter compartment.
- 2** Remove filter from compartment and thoroughly rinse with cool water. This will remove loose charcoal from the filter media.
- 3** Thoroughly rinse the entire bowl and pump compartment.
- 4** Fill the bowl with cool water to about 50% full while lifting the front of the bowl slightly to release air from inside the pump tube.
- 5** Fill the bowl the rest of the way.
- 6** Slide the filter into its location in the filter/pump compartment, rounded edges down. See **Figures (a) & (b) on the right.**
- 7** Place the bowl in the desired location.
- 8** Plug the bowl into an electrical outlet.



**Note:** If water flow does not start immediately, lift the front edge of the bowl slightly to help release air from pump tube. This will help the pump "grab" water. Remember this trick when cleaning the pump.

#### RESERVOIR TANK:

- 1** Remove the reservoir from your CleanFlow™ filter bowl.
- 2** Remove cap from your CleanFlow™ reservoir.
- 3** Thoroughly rinse your CleanFlow™ reservoir with fresh water.
- 4** Fill your CleanFlow™ reservoir.
- 5** Plug the hole in the screw on cap with attached plug. This will keep water from splashing out when turning your reservoir upside down for installation. See **Figures (c) & (d).**
- 6** Screw cap onto reservoir snugly.
- 7** Place reservoir onto your pet bowl. The spike in the bowl will release the water and keep your bowl full. See **Figure (e).**




### CARE INSTRUCTIONS

Read all care instructions carefully. With proper care and cleaning your CleanFlow should offer years of hassle free, clean & filtered water for your pets.

#### CLEANING INSTRUCTIONS:


- 1** Unplug the unit from the electrical outlet and carefully carry to sink.
- 2** Remove lid or reservoir. Rinse and set aside.
- 3** **FILTER:** Remove filter and rinse thoroughly about once per week - as you are refilling the reservoir is a good rule of thumb. Set aside.
- 4** **PUMP:** Remove pump from compartment. Remove tube from pump. Clean water tube using the supplied small cleaning brush.
- 5** Hand wash entire bowl with hot soapy water or place into dishwasher. Reservoir is NOT dishwasher safe - rinse thoroughly. Clean reservoir by rinsing and cleaning by hand. Large white cleaning brush provided for your convenience. See **Figure (g).**
- 6** Reassemble following "USE INSTRUCTIONS" #4 through #8.



#### CARING FOR THE PUMP:

**Note:** Every month or so, your pump should be quick cleaned.

- 1** Using a flat head screwdriver or other dull prying instrument, pry the main cover off the pump. See **Figure (h).**
- 2** Remove the oblong impeller cover. See **Figure (i).**
- 3** Remove impeller. See **Figure (j).**
- 4** Rinse impeller and pump assembly well.
- 5** Use a cotton swab to clean impeller receptacle in pump body. See **Figure (k).**
- 6** After rinsing all parts well, place impeller back into pump body.
- 7** Place oblong impeller cover over the inserted impeller.
- 8** Replace main cover onto pump.



#### K&H Limited Two Year Warranty

**Our warranty is as follows:** K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

**To exercise your warranty:** If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.