

# Universal Mount Kitty Sill with Hood™

## Care & Instructions

Made in China  
K&H Pet Products, Central Garden & Pet  
Colorado Springs, CO  
www.khmfmg.com | (719) 591-6950



**Thank you for purchasing the Universal Mount Kitty Sill with Hood™ designed by K&H Pet Products®.**  
When used correctly, your Kitty Sill should provide hours of comfort and window viewing for your cat.

### USE INSTRUCTIONS

Please read all instructions carefully before installation.

- 1** Lay all parts out on a flat surface. Locate the 3 suction cups and clean them to ensure proper adhesion to your window.
- 2** Now locate the 3 clear plastic locking pins and find the 3 open holes in the frame located on the back of the Kitty Sill.
- 3** Insert a suction cup into one of the open holes. Holding the suction cup in place, insert a plastic locking pin into the side of the suction cup as shown. See **Figure 1**. Push the pin all the way through the hole until it locks into place. Once the pin is locked into place you should not be able to remove it from the suction cup. The suction cup is now locked into place on the Kitty Sill frame.
- 4** Repeat the above steps with the remaining two suction cups until all 3 are installed onto the frame of your Kitty Sill.
- 5** Next, turn the Kitty Sill upside down and locate the two legs. See **Figure 2** for the direction in which the legs should be installed on the bottom. Also, make sure the elastic strap is placed under the Kitty Sill to keep your cover in place. See **Figure 2**.
- 6** Make sure the leg is facing in the correct direction with its 3 pegs facing toward you and the back of the Kitty Sill facing away from you. See **Figure 2 and Figure 3**.
- 7** Insert the pegs into the holes and pull toward you until the leg snaps snugly into place. See directional arrow in **Figure 3**. You should hear a resounding snap. Repeat these steps with the second leg making sure to use the same hole placement as the first side.  
  
Next, hold the Kitty Sill up to your window to be sure that it's level. If the Kitty Sill is not level, snap the legs into another position.

### INSTALLING YOUR KITTYSILL ONTO A WINDOW:

- 8** **VERY IMPORTANT:** Using glass cleaner, thoroughly clean and dry the window that will accommodate your Kitty Sill.
- 9** Press each of the 3 suction cups attached to the base firmly against the window. See **Figure 4**. Re-adjust them if needed.
- 10** Lastly, bring the hood up to the window as shown and firmly press its two suction cups against the glass. See **Figure 5**. Re-adjust if needed. At this time, make any further adjustments to the legs, hood and suction cups to achieve a level surface for your kitty.
- 11** Congratulations! You have now given your kitty an innovative K&H Kitty Sill that will provide them with hours of comfort and enjoyment for many years to come.




Figure 1




Figure 2




Figure 3

3 pegs facing towards you      Back of Kitty Sill facing away from you



Figure 4



Figure 5



Finished

**Caution:** As with any suction cup, debris, temperature changes, sunshine and excessive use can weaken the holding power. We recommend removing the suction cups at least once per month to clean the window area, clean the suction cups and then re-install them for optimal strength.

#### K&H Limited One Year Warranty

**Our warranty is as follows:** K&H Pet Products warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material and workmanship.

**To exercise your warranty:** If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Pet Products, with a **dated proof of purchase or original date receipt**. A return authorization number can be obtained by calling (719) 591-6950 and must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.

#### Care Instructions:

Remove cover. Hand wash only & line dry.