



# INSTRUCTION MANUAL

## B.O.S.S. RECHARGEABLE LITHIUM ION

### HANDHELD SHOWER

#### F235897

**IMPORTANT:** Read these instructions before for use. Keep these instructions for future reference

### WARNING

- Do not leave appliance unattended when in use. Switch the unit off and remove from water when not in use.
- Use only as described in this manual with manufacturers recommended attachments and replacement parts.
- Do not use the shower with water from the sea, pool or river or with any liquid other than water.
- Ensure that the base of the pump is fully submerged in water before operation.
- When the shower is operated by children, proper instruction and attention should be given.
- Recharge the pump using specification required. Output: 5V / 0.5-2A.
- Do not use damaged power cord or plug and charge only with correct voltage as listed on the shower plate. Using improper voltage may result in damage to the motor and possible injury to the user.
- Before use, ensure that there are no broken or worn parts and that all screws are fully tightened.
- Keep the shower away from heating or fire.
- Keep the shower away from freezing. Freezing will damage the motor and cord.
- Do not remove cover plate or attempt to disassemble your machine. This will void all warranties.

### ASSEMBLY INSTRUCTIONS:

1. Attach inlet connector to pump and tighten by turning counter-clockwise. Ensure a tight connection to avoid leakage.
2. Insert O-ring into outlet connector.
3. Attach outlet connector to shower head and tighten by turning counter-clockwise

### OPERATING INSTRUCTIONS:

1. Push on/off switch to start.
2. Put pump into water
3. Position shower head using supplied hook or holder.

### IMPORTANT:

- Do not remove the pump from water when operating. Power off the pump before removing.
- Ensure the shower head is securely mounted before use.

### RECHARGING INSTRUCTIONS:

1. Open socket cover by turning clockwise.
2. Insert USB charging cord (15) into charging socket.
3. Plug USB charging cord (15) into:
  - Mobile phone charger (2.5h)
  - USB output from car (2.5h)
  - USB output from laptop (5h)

### IMPORTANT:

The shower device will stop automatically when voltage is lower than 2.7V for battery protection system.

NOTE: Please do not restart the shower device but recharging it.

### MAINTENANCE:

#### UNATTACH SHOWER DEVICE:

1. Stop the device by pressing the on/off switch.
2. Remove hose from pump and shower head. Drain any water from hose.
3. Remove O-ring from outlet connector and store safely

#### FILTER CLEANING:

1. Remove filter cover .
2. Clean the filter net (5) and filter cover.
3. Replace filter net and filter cover.

### SPECIFICATIONS:

Volt	3.7V	Battery Capacity	2200mAh
Max. Electric Flow:	2.0A	Run Time	45-60 mins
Water Flow	2.2L/Min.-.58 Gal/Min.	Charging	USB output of 5V, 0.5-2A
Power Supply	Lithium Battery	Charging Time	2-5H
**Charge time depends on device being used**			

### PACKAGED ITEMS

- 
- 1) Pump
  - 2) On/Off switch
  - 3) Charging socket
  - 4) Socket cover
  - 5) Filter Net
  - 6) Filter cover
  - 7) Hose
  - 8) Inlet connector
  - 9) Outlet connector
  - 10) O-ring
  - 11) Shower head
  - 12) Holder
  - 13) Hook
  - 14) Suction cup
  - 15) USB Charging cord

### BATTERY INFORMATION:

1. We recommend charging the battery fully after each use to ensure the maximum battery life. **Please charge before using for the first time.**
2. Please recharge the battery at least every three months to ensure it remains in a fully charged state- the battery will deplete when stored for long periods.
3. Do not charge the battery beyond output specification the products required (Output: 5V / 0.5-2A.).
4. Check the battery clamps regularly to find out if it is loose, corrosive or defective or leakage. Maintenance maybe required.
5. Store away from high temperatures or flammable & explosive goods