



**1-800-779-2102**

Mon – Thurs: 8:00am - 5:00pm | Friday: 8:00am - 4:00pm CST

**INSPECT YOUR PRODUCT FOR DAMAGE & MISSING PARTS BEFORE PROCEEDING TO INSTALLATION**

**PROCEDURE FOR RETURNS OR MISSING HARDWARE**

-PLEASE CONTACT THE ORIGINAL POINT OF PURCHASE FOR:  
SHIPPING DAMAGE, RETURNS, OR WARRANTY CLAIMS

-CONTACT DEE ZEE DIRECTLY FOR MISSING PARTS OR HARDWARE

**WWW.DEEZEE.COM**

REGISTER YOUR PRODUCT ONLINE: [www.deezee.com/registration](http://www.deezee.com/registration)

VIEW INSTRUCTIONS ONLINE: [www.deezee.com/instructions](http://www.deezee.com/instructions)

---

**⚠ WARNING:** Cancer and Reproductive Harm  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

Operating, servicing, and maintaining a passenger vehicle can expose you to chemicals such as lead, phthalates, engine exhaust, and carbon monoxide that are known to the State of California cause cancer and birth defects or other reproductive harm. To minimize exposure, service your vehicle and its accessories in a well-vented area and wear gloves or wash your hands frequently.



## DEE ZEE, INC. WARRANTY AGREEMENT

Dee Zee, Inc. guarantees the original purchaser a limited lifetime warranty against manufacturer defects in materials, workmanship, and design under normal use, excluding damage resulting from road hazards such as gravel or other debris, product misuse, improper installation, impairments from accidents, product modifications, improper repairs, spills, vandalism, product neglect, or acts of God.

This warranty applies only to the original purchaser of new product(s) and is limited to the replacement of genuine Dee Zee products. Modification of any kind to Dee Zee products voids all warranty coverage. Warranty does not include electrical components, installation, cost of removal, labor, transportation costs, loss of use, inconvenience, or consequential damages.

### WARRANTY COVERAGE - MATERIALS & WORKMANSHIP

#### **LIMITED LIFETIME WARRANTY:**

- **STAINLESS STEEL:** Side Steps, Grill Guards, Bull Bars, Bed Caps, and Side Rails
- **ALUMINUM:** Side Steps, Running Boards, Storage Boxes, Transfer Tanks, Bed Protection, Side Rails, Invis-A-Racks, and Cab Racks
- **PLASTIC:** Storage Boxes
- **OTHER:** Front and Rear Bumpers

#### **THREE-YEAR WARRANTY:**

- **POWDER-COATED / E-COATED STEEL:** Side Steps, Running Boards, Storage Boxes, Transfer Tanks, Cab Racks, Sport Bar Ladder Racks, Cargo Carriers, Mounting Brackets (NX, Rough Step, and Bumper Guards only)
- **OTHER:** Tailgate Assist, Bed Mats, Floor Mats, Auxiliary Fuel Connection Kits, and All Products Not Otherwise Listed Individually

### WARRANTY COVERAGE – FINISH PROTECTION

The finish of all Dee Zee products is covered for one-year (1) from the date of purchase. Dee Zee products have a high quality finish that must be cared for and maintained like any other exposed finish on the vehicle. Protect the finish with non-abrasive automotive wax (e.g. Pure Carnauba) on a regular basis. Applying soaps, polishes, or waxes that contain an abrasive compound may scratch the finish and leave the exposed material susceptible to corrosion.

### WARRANTY COVERAGE – COMPONENT PARTS

Operational items such as shocks, latches, hinges, and wear items including, but not limited to, mud flaps, step pads, toolbox tray, end caps, hardware, seals, etc. have a one-year (1) warranty. Replacement component parts can be ordered via credit card (MasterCard or VISA) by calling 1-800-779-2102. All replacement parts are non-returnable and non-refundable.

## **GPI® FUEL PUMPS & ACCESSORIES**

All Great Plains Industries (GPI) products, including transfer tank pumps and fuel meters are covered by GPI's warranty policies. Dee Zee's warranty terms do not apply to GPI products. To submit a warranty claim, please contact GPI at 1-800-835-0113 or visit [www.gpi.net](http://www.gpi.net).

### **WARRANTY SUBMISSION PROCEDURE**

All warranty claims will be initiated at the place of purchase. The original purchaser will be required to present the original sales receipt with purchase date shown and provide photographs of the defect.

In the event the originally purchased product style is no longer available, Dee Zee will warranty the defective part with a current equivalent. If a comparable product is no longer available, the product would be returned to the store of purchase for a refund or the applicable cost difference can be paid to choose an alternate style.

### **DISCLAIMER**

All products are sold as appearance accessories and should not be relied upon as protection for the vehicle or its occupants in the event of an accident. Vehicles equipped with a supplemental restraints system (air bags) deployed by impact and collision avoidance systems should not be modified in any way. Always consult the vehicle manufacturer if you have any questions regarding supplemental restraint systems and sensors.

Buyer must accommodate front and rear sensors during product installation and assumes all risk should these be tampered, rerouted, severed, or disconnected. This includes disabling visual, audio, or vibration alerts into the cab. Buyer assumes all risk and responsibility for wiring any supplemental auxiliary lights.

Buyer assumes all risk, liability, and cost for the installation and use of Dee Zee products. Dee Zee, Inc. assumes no liability for injury, loss, incidental or consequential damages in the event of an accident.



Thank you for choosing Dee Zee to add function and accessorize your vehicle. Dee Zee has been a staple brand in the truck accessory market since 1977 and we hold a reputation of quality manufacturing based in America's Heartland. Our products are born through careful engineering and backed by industry leading warranty programs. We appreciate the opportunity to serve you and your vehicle!

**Review the instruction pages in their entirety to prepare the required tools**

**Warning:** Please check for wiring or other obstructions before drilling any holes in the vehicle. If it is necessary to drill any holes, Dee Zee recommends putting a sealant or rust inhibitory around all holes drilled into the body of the vehicle.

It is the sole responsibility of the vehicle owner to check for tire clearance. It is unlawful and dangerous to ride on any external vehicle step while the vehicle is in motion.

**Cleaning:** To be entitled to all warranty rights offered with the product, Dee Zee steps need to be cleaned regularly with a mild detergent. Do NOT use abrasive cleaners. For stainless steel products, the application of a high grade automotive wax is recommended.



Dee Zee Cares - Please Recycle



















For an electronic version of these instructions visit: [www.deezee.com/instructions](http://www.deezee.com/instructions)

Register your product online: [www.deezee.com/registration](http://www.deezee.com/registration)

# Dee Zee Britetread Running Board Installation Instruction

DZ 2036 DZ 2050


(1999 - Current) Ford Superduty Regular Cab Pickup

<p><b>A</b> Britetread Running Board</p>  <p>X2</p>	<p><b>B</b> Britetread Mudflap</p>  <p>X2</p>	<p><b>C</b> Rocker Panel Bracket</p>  <p>X4</p>	<p><b>D</b> Running Board Bracket</p>  <p>X4</p>	<p><b>E</b> 1/4 x 3/4" Hex Head Bolt</p>  <p>X4</p>	<p><b>F</b> 1/4" Flat Washer</p>  <p>X16</p>
<p><b>G</b> 1/4" Hex Nut</p>  <p>X12</p>	<p><b>H</b> 1/4 x 1" Ribneck Carriage Head Bolt</p>  <p>X8</p>	<p><b>I</b> 3/8 x 1" Hex Head Bolt</p>  <p>X8</p>	<p><b>J</b> 5/16" Flat Washer</p>  <p>X28</p>	<p><b>K</b> 3/8" Hex Nut</p>  <p>X8</p>	<p><b>L</b> 3/8" Lock Washer</p>  <p>X8</p>
<p><b>M</b> 1/4 x 1" Sheet Metal Screw</p>  <p>X4</p>	<p><b>N</b> 8mm x 30mm Hex Head Bolt</p>  <p>X8</p>	<p><b>O</b> 8mm Flange Nut</p>  <p>X4</p>	<p><b>P</b> 8mm U-Clip</p>  <p>X4</p>	<p><b>Q</b> Bulb-Seal Gasket</p>  <p>10.5 ft.</p>	<p>1/4" Needed 3/16" Needed</p> 


**Tools Required:**  
**Outils Nécessaires:**




Level




Tin-snips



Phillips Head Screwdriver




Tape Measure



Ratchet / Wrench

Sizes: 3/8"  
7/16"  
9/16"  
13mm





Drill

**1**


Secure britetread mudflap (B) to britetread running board (A) using 1/4 x 3/4" hex head bolts (E), 1/4" flat washers (F), and 1/4" hex nuts (G). Tighten into place using a 7/16" wrench / or socket. Place bulb-seal gasket (Q) onto the backlip of britetread running board (A) and trim flush with the britetread mudflap (B) and the end of britetread running board (A).

Fixez le mudflap de britetread (b) au panneau courant de britetread (a) en utilisant les boulons de tête d'hexa de 1/4 x de 3/4"(e), les rondelles de 1/4" (f), et les écrous 1/4"d'hexa plats (g). Serrez dans l'endroit à l'aide d'une clé de 7/16"/ou du plot. Placez la garniture d'ampoule-joint (q) sur le backlip du panneau courant de britetread (a) et équilibrez à affleurement du mudflap de britetread (b) et de l'extrémité du panneau courant de britetread (a).



**Britetread  
Running Board**





7/16" Wrench  
or Socket



**2**


Locate the existing holes in the vehicle rocker panel as shown below. Place an 8mm u-clip (P) onto the holes shown below and press firmly into place.

Trouvez les trous existants dans le panneau de culbuteur de véhicule comme montré ci-dessous. Placez un u-clip de 8mm (p) dans les trous montrés ci-dessous et appuyez fermement dans l'endroit.



**U-Clip Installed Correctly**

**Vehicle Rocker Panel**



**3**


Using the drawing below as a guide identify the rocker panel bracket and its correct position on the vehicle.

**Note:** The open face of rocker panel bracket (C) will face the rear of the vehicle on the driver side of the vehicle.

**Note:** The open face of rocker panel bracket (C) will face the front of the vehicle on the passenger side of the vehicle.

Align the top hole as shown below with the 8mm u-clip (P) and secure into place using an 8mm x 30mm hex head bolt (N) and 5/16" flat washer (J). Now secure the bottom hole in the rocker panel bracket (C) to the hole in the bottom of the vehicle rocker panel using an 8mm x 30mm hex head bolt (N), 5/16" flat washers (J), and 8mm flange nut (O). Leave fasteners loose for later adjustment.

En utilisant le schéma ci-dessous comme guide identifiez la parenthèse de panneau de culbuteur et sa position correcte sur le véhicule. **Note :** Le visage ouvert de la parenthèse de panneau de culbuteur (c) fera face à l'arrière du véhicule du côté de gestionnaire du véhicule. **Note :** Le visage ouvert de la parenthèse de panneau de culbuteur (c) fera face à l'avant du véhicule du côté de passager du véhicule. Alignez le trou supérieur comme montré ci-dessous avec l'u-clip de 8mm (p) et le fixez dans l'endroit en utilisant un boulon de tête d'hexa de 8mm x de 30mm (n) et la rondelle plate de 5/16"(j). Fixez maintenant le trou inférieur dans la parenthèse de panneau de culbuteur (c) au trou dans le bas du panneau de culbuteur de véhicule à l'aide d'un boulon de tête d'hexa de 8mm x de 30mm (n), des rondelles plates de 5/16"(j), et de l'écrou de bride de 8mm (o). Laissez les attaches lâches pour le réglage postérieur.








**4**

Using the drawing below as a guide, place running board bracket (D) up to rocker panel bracket (C). Secure the rear-top hole in running board bracket (D) to the hole in the rocker panel bracket (C) using 3/8 x 1" hex head bolt (I), 5/16" flat washers (J), 3/8" lock washer (L), and 3/8" hex nut (K). Note: See drawings below for correct hole identification.


En utilisant le schéma ci-dessous comme guide, placez la parenthèse courante de panneau (d) jusqu'à la parenthèse de panneau de culbuteur (c). Fixez le trou d'arrière-dessus dans la parenthèse courante de panneau (d) au trou dans la parenthèse de panneau de culbuteur (c) à l'aide du boulon de tête d'hexa de 3/8 x de 1"(i), des rondelles plates de 5/16" (j), de la rondelle de freinage de 3/8"(l), et de l'écrou d'hexa de 3/8" (k). Note : Voir les dessins ci-dessous pour l'identification correcte de trou.




**5**

Rotate the running board bracket to the upright position and secure it into place using a 3/8 x 1" hex head bolt (I), 3/8" lock washer (L), 5/16" flat washers (J), and 3/8" hex nuts (K) as shown below.

Tournez le panneau courant jusqu'à la position droite et fixez-le dans l'endroit à l'aide d'un boulon de tête d'hexa de 3/8 x de 1"(i), de la rondelle de freinage de 3/8" (l), des rondelles plates de 5/16"(j), et des écrous d'hexa de 3/8" (k) comme montré ci-dessous.




**Rotate**




**6**

Place britetread running board (A) up to the running board brackets (D) as shown below. Slide the britetread running board up to the rocker panel so that it is flush with the vehicle rocker panel.

Placez le panneau courant de britetread (a) jusqu'aux parenthèses de panneau de fonctionnement (d) comme montré ci-dessous. Glissez le panneau courant de britetread jusqu'au panneau de culbuteur de sorte qu'il soit affleurant du panneau de culbuteur de véhicule.






**Side View of rocker panel bracket and britetread running board assembly.**



**7**


Using the bottom holes in the running board bracket (D) as a guide, drill 1/4" holes through the britetread running board. Secure the running board bracket (D) to the britetread running board using 1/4 x 1" ribneck carriage head bolts (H), 1/4" flat washers (F), and 1/4" hex nuts (G). Tighten into place using a 7/16" wrench / or socket.

En utilisant les trous de bas dans le panneau courant encadrez (d) comme guide, forent des trous de 1/4" par le panneau courant de britetread. Fixez la parenthèse courante de panneau (d) au panneau courant de britetread en utilisant les boulons de tête de chariot de ribneck de 1/4 x de 1"(h), les rondelles de 1/4" (f), et les écrous 1/4"d'hexa plats (g). Serrez dans l'endroit à l'aide d'une clé de 7/16"/ou du plot.



**8**

**Drill two holes through the britetread mudflap and the sheet metal of the vehicle wheel well opening. Secure the britetread mudflap to the vehicle wheel well opening using 1/4 x 1" sheet metal screws (M). Tighten into place using a 3/8" wrench / or socket.**



**Forez deux trous par le mudflap de britetread et le métal de feuille de l'ouverture de soute de train de véhicule. Fixez le mudflap de britetread à l'ouverture de soute de train de véhicule à l'aide des vis en métal de feuille de 1/4 x de 1"(mj). Serrez dans l'endroit à l'aide d'une clé de 3/8"/ou du plot.**

