

BIG-4124 Geeler COMPONENTS





ASSEMBLED BIG-4 WHEELER

• RATCHETS:
1/2" and 24mm
• WRENCHs:
1/2" and 24mm
• SCREWDRIVER

Hardware:

• Back Wheels (2)

• 6 cubic ft Tray

- 3" round head bolts: 8pcs
- 2-1/4" round head bolts: 2pcs
- 1" hex bolt with washer: 10pcs
- 1" round head bolts : 2pcs
- Nuts: 22pcs
- Big nuts: 4pcs
- Big washer: 4pcs
- Rubber washer: 4pcs

BIG-4124eeler

8 and 10 Cubic Foot Wheelbarrow

Let the BIG-4 Wheeler DO THE WORK FOR YOU!

Just Push it! NO LIFTING or BALANCING!




WARNING: Not a toy

LITTLE-4 W24eeler

Distributed by:
Custom Quest
www.custom-quest.com
866-346-2250
© 2012 Made in China

BIG-4104eeler ASSEMBLY INSTRUCTIONS



LEG SUPPORT

SUPPORT

B

STEP 1

Insert four 3-inch flat head bolts to the inside of tray through to the bottom of tray, and attach rubber washer to the bolts on the bottom side of tray to keep bolts in place while assembling (Fig. A)

STEP 2

Turn barrow upside down and lay support straps, handles and leg supports over bolts and loosely fit nut over bolt. (Repeat other handle side) (Fig. B)

STEP 3

LAY LEG

SUPPORT ON

TOP OF HANDLE,

SLIDING BOLT

THROUGH HOLES

OVER BOLT.

WOOD

Attach front bump bracket with the only two 2-1/2" bolts as seen in illustration. Tighten. (Fig. C)

STEP 4


Attach back wheel bracket to leg supports with 1" bolts as seen in illustration. Do not tighten. (Fig. D)


STEP 5


Attach back support plate with 1" bolts as seen in illustration. (Fig. D) **Now tighten steps 2, 4, 5.**

STEP 6


Attach front wheel bracket with four 3" bolts (align slotted bolt holes with holes in handle). Slots are there for adjustments to the front wheels to make sure barrow rolls straight. If barrow tends to roll right or left, loosen bolts slightly and bump front wheel bracket to the right or left and tighten. Roll and test to assure that barrow rolls straight. (Fig. E)







BIG-4 W24eeler ASSEMBLY INSTRUCTIONS



STEP 7

Attach front support plate with two 1" bolts (with barrow upright) connecting to the extra holes on the front wheel bracket (as seen in illustration). Then at the top attach the only two flat 1" bolts from the inside of barrow through to bracket. Tighten. (Fig F)

STEP 8

Attach the two front wheels using no washers, just the nut. Tighten until wheel stops turning, then back up nut slightly until wheel rolls freely. (Fig G)

STEP 9

Attach the two rear wheels using a washer on the inside and the outside of wheel for extra stability. Tighten until wheel stops turning, then back up nut slightly until wheel rolls freely. (Fig H) Inflate wheels til firm. Do not over inflate.

