

## TRUCK CHEST MOUNTING INSTRUCTIONS

**Please read these instructions first so you will be familiar with the procedures**

**NOTE:** If your truck has a bed liner, you will have to use these instructions as a guide only. Due to the many differences in bed liner thickness and fit, longer attaching devices are recommended. You will need to insure that your truck chest is mounted securely to the truck, not the bed liner.

### FOR TRUCKS WITHOUT BED LINERS:

1. Place the toolbox in the location desired. Make sure the bottom is in full contact with the truck bed and that the lid will operate without interference. Some trucks have a radius junction where the side of the bed meets the floor and will prevent the chest from sitting flat on the floor. If this is the case, the next smaller chest may fit better.
2. Find the location of the "ridges" (high points) in the bottom of the truck bed. You will need to know where these are located when you anchor the chest to the floor. See the drawing below for example.
3. Decide where to place four (4) mounting screws through the box bottom and into the floor ridges. Screws between 3/16" and 1/4" work best. Look under the truck bed to insure you will not be drilling into any electrical or fluid lines.
4. Center punch the locations where the screws will be located. Drill the correct size holes for the screws you select, or use self drilling type screws.
5. Before you tighten the screws completely, seal the holes by applying a caulk or silicone sealant. Some chest installers remove the screws and reinstall them through rubber washers. The purpose of this is to keep water from entering the box from the holes and screws just installed.

**WARNING:** Any leaking caused by unsealed holes in the box bottom will void the warranty.

