

treeline®

treeline®



HEAVY DUTY RUBBER LATCHES



ROTOMOLDED CONSTRUCTION
STRONG AND DURABLE



NON-SLIP BOTTOMS
KEEPS YOUR COOLER IN PLACE



FREEZER-GRADE RUBBER GASKET
TIGHT SEAL BLOCKS OUT THE HEAT,
LOCKS THE COLD INSIDE



HEAVY DUTY HANDLES
ULTRA STRENGTH POLYESTER ROPE




BOTTLE OPENER
DUAL STAINLESS STEEL LOCKING PLATE FOR MORE
SECURITY WITH BOTTLE OPENER FUNCTION



QUICK DRAIN SYSTEM



TIE-DOWN SLOTS
KEEP IT IN PLACE REGARDLESS OF THE
ACTIVITY YOU ARE PERFORMING




Distributed by: TRACTOR SUPPLY COMPANY
5401 VIRGINIA WAY, BRENTWOOD, TN37027
For customer support, call: 1-888-376-9601
[www. TractorSupply.com](http://www.TractorSupply.com)
MADE IN CAMBODIA


External Dimension: 68.58(L) * 41.4(W) * 41.4(H)cm/ 27(L) * 16.3(W) * 16.3(H) inch
Net Weight: 12.00kg/26.45lbs
Volume Capacity: 45quart equals 42.58 liter approx.

treeline


Roto-molded
cooler
45QT



Leak Proof Gasket Seal for optimal cooler performance



Durable latch design



Anti-Slip foot pads for stability



The stainless steel lock can also be used as a bottle opener



Large drain plug provides fast and easy draining of liquid contents

Tips to make your coolers best performance:

- Pre-chilling. treat your cooler as a temperature maintainer. Now that you think about it in this way, you can understand why it is so important to bring the internal temperature of the cooler down before adding ice. This process is referred to as pre-chilling and is essential for the proper operation of your Cooler. We recommend placing dry ice in the cooler for at least 1 hour. Always use proper safety precautions when handling dry ice including the use of gloves. If dry ice is not available place the cooler in a chest freezer overnight. Another option is to fill up the cooler with ice and leave overnight, then change to fresh ice before using.
- If possible, chill or freeze any goods before placing them in the cooler. The ice will last much longer.
- Water from melted ice is not a bad thing! Cold water that comes from ice after a few days helps insulate the remaining ice better than empty airspace.
- Open your lid as few times as possible to reduce warm air coming from the outside. Always shut the lid with latch lock in correct position after you opened the cooler.
- Ice performance can vary greatly. Block ice will melt slower than cube ice, but cube ice with a larger total surface area will cool items faster. You may want to consider a mixture of both types. Start with very cold, solid ice versus wet ice that has already begun to melt. Besides, the temperature, times you open the lid, will also influence the ice performance too.
- Fill cooler with as much ice as possible.
- Your cooler is dry ice approved. Dry ice (CO₂), made from frozen carbon dioxide, is an excellent way to achieve super cold temperatures, without any water residue. Always handle dry ice with caution and wear protective gloves, as it can quickly freeze burn skin (-109°F). Allow for adequate ventilation of any CO₂ gas. It may be helpful to add some dry ice to your ice mixture to keep it colder longer.