
























Loveseat Glider  
CO1024



## PART LIST


|   |   |   |  |   |
|---|---|---|--|---|
| <b>A</b><br> | <b>B</b><br> | <b>C</b><br> | <b>D</b><br> | <b>E</b><br> |
| Left Leg<br>1 PC  | Right Leg<br>1 PC   | Leg Support<br>1 PC   | Support<br>2 PCS   | Connecting Wire<br>2 PCS  |
| <b>F</b><br> | <b>G</b><br> | <b>H</b><br> | <b>I</b><br> |   |
| Left Arm<br>1 PC  | Right Arm<br>1 PC   | Back Panel<br>1 PC  | Seat Panel<br>1 PC   |   |

## HARDWARE LIST

|   |  |  |   |   |
|---|--|--|---|---|
| <b>#1</b><br>  | <b>#2</b><br> | <b>#3</b><br> | <b>#4</b><br> | <b>#5</b><br>  |
| M6x25mm<br>Long Bolt<br>6 PCS (Extra 1)   | M6x20mm<br>Medium Bolt<br>2 PCS (Extra 1)  | M6x16mm<br>Short Bolt<br>17 PCS (Extra 3)  | Self-Locking Nut<br>27 PCS(Extra 3)   | Metal Washer<br>56 PCS(Extra 3)   |
| <b>#6</b><br>  | <b>#7</b><br> | <b>#8</b><br> | <b>#9</b><br> | <b>#10</b><br> |
| Plastic Washer<br>8 PCS (Extra 2)   | Adjustable Leveler<br>4 PCS (Extra 1)  | Connecting<br>Screws<br>2 PCS (Extra 2)  | Wrench<br>2 PCS   | Allen Wrench<br>1 PC  |
| <b>#11</b><br> |  |  |   |   |
| Touch Up Paint<br>1 PC  |  |  |   |   |


**IMPORTANT NOTE: WE RECOMMEND AT LEAST TWO PEOPLE WORK TOGETHER TO ASSEMBLE UNIT.**

Step 1. Screw adjustable levelers (part #7) into pre-drilled holes on the bottom of legs (parts A & B).




Step 2. Attach leg support (part C) to legs (parts A & B) using short bolts (part #3), metal washers (part #5), self-locking nuts (part #4), wrench (part #9) and allen wrench (part #10).


NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 3. Attach supports (part D) to legs (parts A & B) and leg support (part C) using short bolts (part #3), metal washers (part #5), self-locking nuts (part #4), wrench (part #9) and allen wrench (part #10).


NOTE: Please do not fully tighten bolts until unit is fully assembled.









- #3  x6
- #4  x6
- #5  x12
- #9  x1
- #10  x1

Step 4. Attach back panel (part H) to seat panel (part I) using medium bolts (part #2), short bolts (part #3), metal washers (part #5), self-locking nuts (part #4), wrench (part #9) and allen wrench (part #10).



NOTE: Please do not fully tighten bolts until unit is fully assembled.










- #2  x2
- #3  x3
- #4  x5
- #5  x10
- #9  x1
- #10  x1




Step 5. Install long bolts (part #1), metal washers (part #5), connecting screws (part #8) and self-locking nuts (part #4) to back panel (part H) using wrench (part #9) and allen wrench (part #10). See Figure 1. Ensure connecting screws (part #8) are on the back of back panel (part H) and sticking out. See Figure 2. Next, connect arms (parts F & G) to assembled unit (parts H & I) using installed connecting screws (part #8), short bolts (part #3), metal washers (part #5), self-locking nuts (part #4), wrench (part #9) and allen wrench (part #10). Ensure assembled unit (parts H & I) is tilted at an angle to line up properly with arms (parts F & G).







NOTE: Please do not fully tighten bolts until unit is fully assembled.




- #1  x2
- #3  x4
- #4  x4
- #5  x10
- #8  x2
- #9  x1
- #10  x1

Step 6. Using at least two people, carefully lift assembled unit (parts F, G, H & I) and place inside assembled unit (parts A, B, C & D).  
 Attach hooks on arms (parts F & G) to swing arms on legs (parts A & B) using long bolts (part #1), metal washers (part #5), plastic washers (part #6), self-locking nuts (part #4), wrench (part #9) and allen wrench (part #10).  
 NOTE: Please fully tighten all bolts at this time.




- #1  x4
- #4  x4
- #5  x8
- #6  x8
- #9  x1
- #10  x1

Step 7. Attach connecting wire (part E) to arms (parts F & G) using metal washers (part #5), self-locking nuts (part #4) and wrench (part #9).



Step 8. Attach connecting wire (part E) to arms (parts F & G) using metal washers (part #5), self-locking nuts (part #4) and wrench (part #9).





Step 9. IMPORTANT NOTE: Please always use at least two people when moving this completed loveseat glider, and be careful of the moving parts.

