



## ORIGINAL CEDAR RAISED GARDEN BED | ASSEMBLY INSTRUCTIONS

Questions? Email [info@greenesfence.com](mailto:info@greenesfence.com) or call 800-622-5510 Monday - Friday 8am-5pm EST

### PACKAGE CONTENTS + (16) Screws



- BUILD A WALL WITH SHORT POSTS.**  
Hold a Board on the ground so it's standing on edge with the notched ends to the left and right. Slide a Short Post down over one notched end of the Board. Next, slide another Short Post over the other notched end. This forms a wall.  
*Repeat this step to complete a second wall.*

- BUILD A FRAME**  
Place the walls parallel to each other and connect them into a square with two more Boards. This forms the frame of the center Garden Bed.



- BEGIN BUILDING FRAMES OUT FROM THE CENTER BED.**  
Slide a Tall Post over one notched end of a Board. Slide the other end of the Board down into one of the Short Posts on the Center Bed to extend out a wall. Repeat until walls extend from all corners of the Center Bed.



- FINISH BUILDING THE FRAMES OF THE FOUR CORNER BEDS.**  
Repeat Step 3 with Tall Corner Posts and Boards to create a third wall on the Corner Beds. Then connect the open Tall Posts with Boards to complete all four corner frames.



- ADD TWO MORE BOARDS TO ALL WALLS.**  
Add Boards, one at a time, directly on top of each existing Board in the frame. Push the Boards down evenly between the tops of the Posts. If needed, tap snugly into place with a rubber mallet.



- ATTACH FOUR MORE SHORT POSTS ON TOP OF THE FIRST FOUR TO CREATE A TALL CENTER FRAME**  
The Posts are taller than the Boards so Beds can be stacked.

- ADD A FOURTH BOARD TO EACH WALL OF THE TALLEST FRAME & ATTACH DECORATIVE CAPS**  
When the Garden Bed is completed, attach each Decorative Cap to a Corner Post with a screwdriver and Screw. We recommend drilling a pilot hole in each Cap first.

