# **ASSEMBLY & INSTALLATION INSTRUCTIONS**

in order to prevent possible shock Turn off the main power at the circuit breaker before installing the fixture,


### Parts included:



## **ASSEMBLY & INSTALLATION**

- 1. Take off the SCREWS (16) on both sides of the CANOPY (15)
- 2. Unscrew the LOOP (6) from the CANOPY (15);
- 3. Thread the HEX NUT (5) several turns onto the top end of the NIPPLE (4);
- 4. Place the NIPPLE (4) into the center of the MOUNTING BRACKET (2):
- S Attach the power supply wires to the fixture lead wires by connecting and the WHITE SUPPLY WIRE (11) to the RIBBED FIXTURE LEAD WIRE (12) the BLACK SUPPLY WIRE (9) to the SMOOTH FIXTURE LEAD WIRE (10) with the WIRE CONNECTORS (13).
- Place wiring and connections inside the OUTLET BOX (1). to the SUPPLY GROUND WIRE (8) using a WIRE CONNECTOR (13) the GROUND WIRE(7).) Connect the remaining FIXTURE GROUND WIRE (7) the MOUNTING BRACKET (2). (Note: Be sure to provide an extra 3" length of Loop the FIXTURE GROUND WIRE (7) around the GROUND SCREW (14) of
- 6. Place MOUNTING SCREWS (3) into the elongated holes of the MOUNTING BRACKET (2) to tighten the MOUNTING BRACKET (2) onto the OUTLET BOX (1);
- Place the CANOPY (15) over the MOUNTING BRACKET (2) with the SCREWS (16) on both sides
- 8. Thread the LOOP (6) onto the bottom end of the NIPPLE (4).

## **INSTALLATION IS NOW COMPLETED!**



- OUTLET BOX
- N MOUNTING BRACKET
- ယ MOUNTING SCREW
- NIPPLE
- HEX NUT

- 10.SMOOTH FIXTURE LEAD **VIRE**
- 11. WHITE SUPPLY WIRE
- 12. RIBBED FIXTURE LEAD WIRE

<u></u> LOOP

- 13. WIRE CONNECTOR
- FIXTURE GROUND WIRE 14. GROUND SCREW
- SUPPLY GROUND WIRE 15. CANOPY
- 9 **BLACK SUPPLY WIRE** 16. SCREW