


Thank you for purchasing this Winsome House product. This product has been manufactured with the highest standards of safety and quality.

Product Name:	Sconce Hurricane Lantern Solar Light
SKU #:	WH101



Instructions:

- For first time use, solar light needs to be charged in full sunlight for 6-8 hours to allow for rechargeable battery to reach maximum capacity.
- Always charge in direct sunlight.
- Turn the on/off switch to the on position and screw the top back on, clockwise
- For best results, allow to charge in direct sunlight for a minimum of 8 hours
- After fully charged, product will automatically light at night
- To extend battery life, turn to the off position when not in use
- Battery: rechargeable AA Ni-MH 400mAh 1.2V 1pc (included)


Installation:



- Two screws and plastic inserts are included. Tools needed: Drill (not included)



- Drill two holes in the wall vertical from each and spaced 4 1/8 inches apart.
- Insert plastic piece into each drilled hole, then insert screw into each plastic piece.
- Lock the sconce hook onto the screw by lining up with the inserts in the large holes in the back of the hook, and then slide down.





Instruction Manual

Please save this manual for future reference.

Product Name:	Sconce Hurricane Lantern Solar Light
SKU #:	WH101

Battery Replacement:

There is battery cover and easy for battery replacement, no tools needed.

Battery model# AA Ni-MH 400mAh 1.2V rechargeable battery

For optimum performance, allow battery to charge in full sunlight.

Troubleshooting:

If your solar light does not turn on at night, it may be caused by the following:

1. Check to see if the switch is in the "OFF" position.

Resolution: Push the switch to the "ON" position and allow the solar light to be charged for at least 8 hours in direct sunlight.

2. Battery may not be fully charged.

Resolution: Make sure the solar light is placed in an area where the solar panel receives the maximum amount of full direct sunlight every day.

3. The solar light may be located too close to other light sources (such as porch light or street lantern).

Resolution: Relocate away from external light source.

4. The rechargeable battery may need to be replaced.

Resolution: Replace with batteries of identical specification.

WARNING:

Do not dispose of batteries in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling batteries or disposing of them in accordance with Local, State, and Federal regulations.