
# INSTRUCTION MANUAL

AIR46





- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Be aware that moving parts can injure, crush and cut.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

## TOOLS REQUIRED










PHILLIPS SCREWDRIVER


DRILL (RECOMMENDED)


2PERSON ASSEMBLY

APPROXIMATELY 60MIN. ASSEMBLY


## HARDWARE























# HARDWARE





#### **CARTON 1/5**






















#### CARTON 2/5















#### **CARTON 3/5**















#### **CARTON 4/5**













#### **CARTON 5/5**
























01

Attach the part A1, part D1 by 2 X P2 screws. Attach the part A2, part D2 by 2 X P2 screws.




Then attach the part B1, part B2,part C to the step 1 by 16 X P1 screws.




03


Slide in the tray Part K. Insert the perches 3xPart I1 into the slots inside the left and right panel of coop.




Attach the perch Part J to the slots inside the front and right panel by 1XP3 screws each side.




Attach the side panels of nesting box Part F1 & F2 to the coop by 6XP3 screws.




Attached the front panel of nesting box Part E to the side by 6XP1 screws.



Attach the another side panels of nesting box Part F1 & F2 to the coop by 6XP3 screws.




Attached the front panel of nesting box Part E to the side by 6XP1 screws.




13


Drop in the bottom panel of nesting box Part G. Slide in the divider 2 x Part H each side.




Attach the roof of nesting box 2 X Part L to the nesting box by 6XP6 screws each side.



Attach the lock 2 X P8 to the nesting box by 6XP6 screws each side.




Attach the coop roof 2xPart N to the coop by 8XP4 screws.



13

Put the Waterproof pvc P9 in the connection position of 2 roof cap to avoid the water leakage.


Then attached the roof cap 2 x Part W by 8XP5 screws.




14

Attach the pen panel Part P1 to the coop by 3XP2 screws.

Attach metal rod Part P7 to the back panel of coop by 2xP6 screws.




Attach the bottom connecting bars Part X by 4XP5 screws, the position is shown in the picture.




Attach the pen panel Part P2 to the coop by 3XP2 screws.


Attach the bottom connecting bars Part X by 4XP5 screws, the position is shown in the picture.




Attach the ramp Part O to the coop by 4XP6 screws.




Attach the perch Part I2 into the slots inside the inner pen panel Part P1&P2 by 2XP3 screws.






Attach the up and down four connecting bars Part X by 4XP5 screws each, the position is shown in the picture.




Attach pen panel Part R1 & R2 to the coop by 6XP2 screws.




Attach the up and down four connecting bars Part X by 4XP5 each, the position is shown in the picture.

Attach the perch Part I2 into the slots inside the inner pen panel Part R1 & R2 by


Attach the perch Part I2 into the slots inside the inner pen panel Part R1 & R2 by 2XP3 screws.




Attach the back pen panel Part S to the pen by 6XP3 screws.




Attach the pen roof Part T & Part U & Part V by 13XP3 screws.




25 Fix the middle roof panel to the side roof panels by 2XP2 screws.



Attached PVC Waterproof Strip Part M to the right side nesting box by 4XP5 screws.



Attached PVC Waterproof Strip Part M to the left side nesting box by 4XP5 screws.





#### WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury,property damage or loss,whether direct,indirect,or incidental,resulting from the incorrect attachment,improper use,inadequate miantenance,or neglect of this