
INSTRUCTION MANUAL



www.aivituvin.com



- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten screws loosely during initial assembly. Do not fully tighten screws until the item is completely assembled.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Be aware that moving parts can injure, crush and cut.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

TOOLS REQUIRED











PHILLIPS SCREWDRIVER DRILL (RECOMMENDED)

2PERSON ASSEMBLY APPROXIMATELY 60MIN. ASSEMBLY


HARDWARE

















HARDWARE




PARTS























PARTS

























PARTS






















01


Attach the coop ! Attach the Part A , Part B , Part G , Part E1 by 6xP1 screws. Attach the panel Part E2 by 6xP1 screws.




02

Slide in the tray Part F.

Insert the perches 2xPart U into the slots inside the front and back panel.




Attach the ramp Part R to the back panel Part B by 4xP6 screws as show on the picture.




Attach the right nesting box!

Attach the panel Part L & M to the right panel of coop by 4xP3 & 2xP4 screws.




05


Attach the panel Part N to the right of nesting box by 6xP1 screws.




Attach the left nesting box! Attach the panel Part L & M to the left panel of coop by 4xP3 & 2xP4 screws.




Attach the panel Part N to the left of nesting box by 6xP1 screws.




Drop in the bottom panel of nesting box 2xPart P to 2 nesting box as show on the picture.




Slide in the divider 2xPart O to each Part P as show on the picture.




Attach the pen!
Attach the panel Part I & H (Close to the coop) to the coop by 6xP2 screws.




Attach the panel Part J1 & J2 (outside) to the Part I & H by 6xP2 screws.




Attach the support frame Part D to the Part J1 & J2 (outside) by 4xP1 screws as show on the picture.




Attach the back panel pact C & K by 2 x p2 screws.




Attach the panel Part C & K to Part J1 & J2 by 8xP1 screws.




Attach 2pcs of perches part V to the pen by 4 x P4 screws each side as show on picture.




Attach the nesting box roof 2xPart Q to the nesting box by 4xP6 screws each side.




Attach the roof 2xPart S & 2x Part T to the coop by 16xP4 screws. (Notice do not confuse the position of Part S & Part T)




Attach the roof cap 2xPart X to the roof by 8xP5 screws.




Connect the roof with connect bar 2xPart W by 12xP5 screws.



Attached PVC Waterproof Strip Part Y to the right side nesting box by 3XP5 screws.



Attached PVC Waterproof Strip Part Y to the left side nesting box by 3XP5 screws.



17



WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury,property damage or loss,whether direct,indirect,or incidental,resulting from the incorrect attachment,improper use,inadequate miantenance,or neglect of this