

Battery Powered Designer Wall Sconce




Contents





- A - Designer Wall Sconce* x 1
- B - LED Back Plate x 1
- C - Shade* x 1

* Shape/Style of Wall Sconce or Shade may vary

Requires



AA Batteries x 6
(Not Included)



INSTALLATION:

1. Remove rear battery cover of the LED Back Plate (B) and place 6 AA cell batteries (we recommend alkaline or rechargeable batteries - not provided) with the polarity as shown in the battery door. Replace battery cover.

IMPORTANT: Pay careful attention to the polarity of the batteries and ensure they are inserted in the correct direction as shown on the battery cover illustration. Failure to install batteries in the correct direction may cause damage to the product.

2. Determine where the product is to be mounted and insert nail or screw (not provided) in the wall.
3. Mount the Designer Wall Sconce (A) to the wall by sliding it onto the nail or screw head like hanging a picture frame. Ensure the nail or screw has a weight capacity of 3 lbs.
4. Gently slide the LED Back Plate (B) into the holder at the top of the Designer Wall Sconce (A).
5. Place the Shade (C) onto the LED Back Plate by fitting the holes in the top of the shade frame onto the Mounting Posts of the LED Back Plate to hold it in place.
6. Push the Power Button located on the bottom of the unit to power the unit on. If the unit has an amber flicker mode, press again to switch from white LED to amber LED. Push the Power Button again to power the unit off inside the ceiling plate. Once set it will stay in place automatically.

Continued on back side.

It's Exciting Lighting is a Smart Living Home & Garden brand © 2018.0

Telephone: + 1 813 343 5775

Email: customerservice@smartlivinghg.com

Web: www.itsexcitinglighting.com

Smart Living Home & Garden



Battery Powered Designer Wall Sconce



USE:


1. This unit contains a built in 4 hour timer which is activated immediately when the unit is switched on. The unit will power off after 4 hours of use. This helps maximize battery longevity. Unit can be turned back on manually to commence a new 4 hour session. Unit can be turned off manually at any time.
2. This unit features an automatic 24 hour timer that will allow the unit to turn on at the same time each day. To activate, simply turn the unit on and let the unit run for the 4 hour time period. The unit will automatically turn off after 4 hours of use and then turn on 24 hours after it was originally turned on. To override this feature simply turn the unit off by pressing the manual on/off button to off.

SAFETY:

1. Do not disassemble the back plate.
2. To prevent equipment damage and possible injury, never mix batteries with different chemistries or voltages in the equipment at the same time.
3. Consumed batteries need to be disposed of properly. Follow the disposal instructions on the battery package. Battery selling retailers provide special containers for environmentally friendly disposal.
4. Remove batteries from unit for long term storage to prevent damage from battery leakage.

INSTALLING AND REPLACING BATTERIES:

1. Remove battery compartment cover on LED Back Plate. Insert new AA alkaline batteries.



WARNING: Pay careful attention to the polarity of the batteries being inserted. NEVER insert batteries with the " + " of one battery facing the " + " of the other. Inserting the batteries incorrectly may cause spark, fire or explosion.

2. Replace battery compartment cover and place LED Back Plate back into the Designer Wall Sconce holder.
3. The LED Back Plate has a separate circuit for both sides of the battery compartment. To make the unit last longer before needing to change the batteries, install 6 AA Alkaline batteries (3 on each side). If you only have 3 AA Alkaline batteries available, the unit can still be used. Simply install the 3 on either side of the battery compartment.

