


12' SENTINEL STALL FRONT LUMBER KIT



LKF12



FOR MORE INFORMATION, QUESTIONS, OR CONCERNS,
PLEASE CONTACT TARTER CUSTOMER SERVICE:

1.800.RED.GATE (1.800.733.4283)

KIT INCLUDES:

SLIDING DOOR

- (5) 46-3/4" X 6-3/4" TONGUE AND GROOVE
- (1) 46-3/4" X 6-3/4" GROOVE ONLY
- (1) 46-3/4" X 5-3/4" GROOVE ONLY

STALL FRONT PANEL

- (3) 36" X 6-3/4" TONGUE AND GROOVE
- (1) 36" X 5-1/4" GROOVE ONLY
- (8) 46-3/4" X 6-3/4" TONGUE AND GROOVE
- (1) 46-3/4" X 6-3/4" GROOVE ONLY
- (1) 46-3/4" X 5-3/4" GROOVE ONLY

TOOLS NEEDED:

- PHILLIPS SCREW DRIVER
- DRILL
- RUBBER Mallet
- TAPE MEASURE
- CIRCULAR SAW

INSTALLATION NOTES:

- It is recommended to have the stall panel in its final location before installing the lumber kit.
- Install Sliding Door first.
- The beveled edge of the boards must be facing outward and the flat edge of the boards facing inward.
- A rubber mallet may be used to secure the boards tightly without damaging them.



GROOVE



TONGUE



BEVELED EDGE

SLIDING DOOR INSTRUCTIONS:

1. Install 5 - 46-3/4" x 6-3/4" tongue and groove boards, with groove towards the frame. The first few boards can be installed by leaning at an angle and sliding in the channel.
2. Install 1 - 46-3/4" x 6-3/4" board, with groove only. Use notch to install final boards.
3. Install 1 - 46-3/4" x 5-3/4" board, with groove only. Make sure the non-grooved side is towards the frame. Last board may need to be cut to fit properly. Cut must be made to the flat edge.
4. Secure lumber with 4 - #10 x 1" Phillips screws. It is important to screw the lumber in so the boards do not come out. (Included in stall hardware)



STALL FRONT PANEL INSTRUCTIONS:

1. Install 3 - 36" x 6-3/4" tongue and groove boards. Make sure groove is towards the frame. The first few boards can be installed by leaning at an angle and sliding in the channel.
2. Install 1 - 36" x 5-1/4" board, with groove only. Board may need to be cut to fit properly. Cut must be made to the flat edge.
3. Install 8 - 46-3/4" x 6-3/4" tongue and groove boards. Make sure groove is towards the flat edge of the previous board.
4. Install 1 - 46-3/4" x 6-3/4" board, with groove only. Use notch to install final boards.
5. Install 1 - 46-3/4" x 5-3/4" board, with groove only. Make sure the non-grooved side is towards the frame. Last board may need to be cut to fit properly. Cut must be made to the flat edge.
6. Secure lumber with 4 - #10 x 1" Phillip screws. It is important to screw the lumber in so the boards do not come out. (Included in stall hardware)

