
### STYLE NO: 6310-10043 Supreme Over The Fridge Shelf





Part	Reference
A	F12163
В	F12164
С	F12165
D	F12166
E	F12167
F	F12168
G	F12169
Н	F12170
I	F12171
J	F12172
K	F12173
L	F12174
М	F12175
N	F12176
0	F12177



NOTE: Bottom frame (E) and shelves (F) and (G) are padded with disks. Throw away the disks as you unpack the shelves.

This product's intended use is for storage in all environments in a home or commercial setting. The shelf capacity is 30 lb. when weight is evenly distributed.

**Tools Needed: Phillips screwdriver** 

**A** 4 ea Bottom Poles (18.25")



**E** 1 ea Bottom Frame






**F** 1 ea Bottom Shelf



**G** 1 ea Top Shelf

Middle Rear Poles (13.88")

**D** 2 ea Top Rear Poles (23.625")



**1** 1 ea Hooks



**J** 28 ea Sleeves



**Threaded Connectors** (Pre-installed on A & C)



**M** 1 ea Wall Screw

**N** 1 ea

Wall Anchor

**H** 2 ea

Shelf Supports

0 **O** 1 ea

Washer




### **STEP 1: Pole Assembly**

- □ To assemble front poles, connect two bottom poles (A) and two top front poles (B) by threading connectors (K) into open end of the poles.
- □ To assemble rear poles, connect bottom pole (A), middle rear pole (C) and top rear pole (D) using threaded connectors (K).

### NOTE:

- □ Connectors are already be preinstalled to poles (A & C).
- □ Feet are already be preinstalled to poles (A)




# 

### STEP 2:

- □ Snap two sleeves (J) onto bottom of each pole at the first double groove - three grooves will be visible below. The sleeves are marked with a directional arrow to show proper placement.
- □ Slide bottom frame (E) down onto the sleeves, making sure the long rear poles are at the back and the short poles are at the front, push or gently tap until snug.

### NOTE:

- □ Do not place additional sleeves until the frame is installed.
- □ Make sure cone shape and notches on




# 6310-10043 Supreme Over The Fridge Shelf




## STEP 3:

- □ Snap two sleeves at the tops of each front poles and on the same level on the rear poles.
- □ Use grooves to ensure even shelf placement among the four poles.
- □ Slide the bottom shelf (F) down, push or gently tap until snug.



### STEP 4:


- □ Using sleeves (J) attach the shelf supports (H) with seven grooves visible below.
- □ Using sleeves (J) attach the hooks (I) with three grooves visible below.






#### STEP 5:

□ At the top, use sleeves (J) to attach the top shelf (G), place the shelf supports (H) in the holes on the shelf.



### Anti-Tip Kit Attachment

□ To prevent tipping, attach this unit to a wall. Install the wall anchor (N) using a Phillips screwdriver (not included). Place a washer (O) under the top shelf as indicated and attach with the wall screw (M). Use a Phillips screwdriver to tighten.



8680 Swinnea Road • Suite 103 • Southaven, MS • 38671

**NEED HELP?** For help with assembly, or if you are missing a part, please call Whitmor's Consumer Care Team, 1-888-944-8667 between 8 a.m. and 4:30 p.m. (Central Standard Time) Monday through Friday, or email: help@whitmor.com. Visit us online at www.whitmor.com