

JS AC 5000 LUMEN LED WORK LIGHT



User Manual



JS AC 5000 LUMEN LED WORK LIGHT

CONTENTS

- 1 LED Worklight
- 1 R7S LED bulb

IMPORTANT SAFETY INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION, OR PERSONAL INJURY

WARNING - Lighted lamp is HOT:

WARNING - To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION, OR PERSONAL INJURY:

- 1) Turn off/unplug and allow to cool before replacing bulb (lamp).
- 2) Bulb (lamp) gets HOT quickly! Only contact switch/plug when turning on.
- 3) Do not touch hot lens, guard, or enclosure.
- 4) Do not remain in light if skin feels warm.
- 5) Do not look directly at lighted lamp.
- 6) Keep lamp away from materials that may burn.
- 7) Use only with a 500 watt or smaller bulb (lamp).
- 8) Do not touch the bulb (lamp) at any time. Use a soft cloth. Oil from skin may damage bulb (lamp).
- 9) Do not operate the portable luminaire with a missing or damaged guard, lamp containment barrier, or UV filter.

READ ALL INSTRUCTION WARNINGS:

When portable fixtures are used outdoors, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following:

A. Use only three wire outdoor extension cords that have three prong grounding plugs and receptacles that accept the worklight plug.

B. Ground fault circuit interrupter (GFCI) protection should be provided on the circuit(s) or outlet(s) when the worklight is used in wet locations.

C. Use only with extension cord for outdoor use, such as an extension cord type SW, SOW, SOW-A, STW, STW-A, STOW, STOW-A, SJW, SJW-A, SJOW, SJOW-A, SJTW, SJTW-A, SJTOW, SJTOW-A.

D. CAUTION: TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, USE ONLY OUTDOOR RATED CORDS OF APPROPRIATE LENGTH. DO NOT USE MULTIPLE EXTENSION CORDS.

Safety Instructions for LED Worklight


- Always wear safety glasses when working in close proximity of the worklight while energized, or when fixture is off and you are replacing the bulb.
- Keep fixture 18 inches away from combustible materials such as cloth, wood, or paper. Lighted fixture gets hot! This fixture should not be used indoors.
- Do not look directly at bulb when in use.
- Keep fixture away from children.
- When replacing the bulb always turn off, unplug, and give ample time for lamp to cool. Do not touch the bulb with your fingers as oil from your skin will damage the bulb and greatly shorten bulb life. Always close face of fixture securely before turning power back on.
- Never operate the fixture without glass safety shield or safety grill installed.
- This fixture is not intended for use in potentially dangerous locations such as areas with explosive or flammable atmospheres.
- Do not handle this fixture when standing on damp surfaces or in water. To reduce the risk of electrical shock, this light should always be plugged into properly grounded 3 wire outlet. Do not remove the ground wire of grounded plug from the fixture. Always use a U.L. listed 3 wire grounded cord with electrical capacity to properly handle this light and other tools you might be using. Never use light around swimming pool, hot tubs or saunas.
- Never use around volatile fluids such as gasoline.
- Never use bulb larger than the fixture rating, as fixture will get hot and unsafe to use.

INSTRUCTIONS GENERAL & NSTRUCTIONS-GÉNÉRALITÉS

1. Added weight of the device may cause instability of a free standing portable luminaire & le dispositif constitue un poids supplémentaire ce qui peut causer l'instabilité d'un luminaire portable autonome.
2. Use only with a portable table lamp that is provided with a shade & utiliser uniquement avec une lampe de table dotée d'un abat-jour.
3. Use in portable table lamps in which the distance from the bottom of the base to the top of the lampholder does not exceed three & utiliser avec une lampe de table pour laquelle la distance entre la partie inférieure du socle et la partie supérieure de la douille de lampe n'est pas supérieure à 3 fois le diamètre minimal du socle.
4. This device is not intended for use with emergency exits & ne convient pas aux sorties de secours.

Note: Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

INSTRUCTIONS FOR WIRE SAFETY GRILL INSTALLATION



WARNING: GRILL MUST BE INSTALLED ON WORKLIGHT BEFORE OPERATION




1. Slide top right prong flat against glass and into top right slot.
2. Once prong is in slot, slide to the left.
3. Push top left prong into top left slot. Prongs are now locked.
4. Squeeze grill and slide bottom left prong into bottom left slot.
Once prong is in slot slide to the right.
5. Slide bottom right prong into bottom right slot. All four prongs are locked.
6. Check to make sure all four prongs are locked before using.

WARNING - THIS FIXTURE GETS VERY HOT!!!

Never use this fixture without the safety grill in place. The safety wire grill provides protection in the event that the fixture tips over and also protects against accidental touching of the hot safety glass. Never use this fixture around children. Do not use around combustible materials such as gasoline or flammable paints.

INSTRUCTIONS FOR BULB INSTALLATION

- If required, allow the fixture to cool before attempting to change the bulb.
- For safety reasons always unplug the fixture from the outlet before attempting to change the bulb. The switch could accidentally be turned on resulting in personal injury.
- First loosen the face screw knob on the frame holding the safety glass and grill in place.
- To remove the old bulb, push the bulb gently to the right until the left hand end slides easily out of the socket.
Insert the right end of bulb against the right hand contact of the socket and push very gently until the left hand end is free to come into contact with the left socket. Be sure both ends of bulb are securely seated against both socket contacts.
- Carefully replace the safety glass face of the fixture and tighten the face screw knob, do not overtighten.
- Always be sure to use a grounded outlet for your 3-wire grounded lamp cord.



WARNING: Do not look directly at the worklight or shine into anyone's eyes. Eye damage may result.

- Bulb life varies based on handling and voltage surges. As a result, the bulb is not warranted. Using the fixture in a horizontal position will extend the bulb life. Use of improper bulbs will void the warranty on this fixture.

Trouble Shooting

If light does not work, check the following:

- A. Ensure the power source is functioning and the fixture is properly plugged into the power source.
- B. Ensure the bulb is installed correctly and both ends are making proper contact.
- C. Bulb may have been damaged in shipment. Check with a continuity tester. If bad, replace with a new bulb.

SATISFACTION GUARANTEED

If for any reason you are not completely satisfied with your purchase, please return it to any Tractor Supply Co.® Store.

SAVE THESE INSTRUCTIONS!

Distributed by:
TRACTOR SUPPLY COMPANY
5401 VIRGINIA WAY
BRENTWOOD, TN 37027
For customer support, call: 1-888-376-9601
www.TractorSupply.com
MADE IN CHINA